

Sugon I620-G20

User's Manual

DAWNING INFORMATION INDUSTRY CO., LTD.

Statement

This manual is intended to help users to use the server product of Sugon correctly (hereinafter referred to as "This Product"). Please read all accompanying materials carefully before you install and use this product for the first time, especially for the considerations mentioned in this manual. This will help you to better use this product safely. Please keep this manual properly for the future reference.

The description in this manual does not represent any description of the specification and software/hardware configuration for this product. For the actual specification and configuration of this product, please refer to relevant agreements, packing lists and description files of product specification and configuration, or consult with distributor of this product.

If you fail to install, use or keep this product correctly and in accordance with the instructions and requirements of this manual, or enable the technical personnel without the authorization of Sugon to repair and change this product, Sugon will not be liable for any damage resulting therefrom.

The photos, graphs, charts and illustrations in this manual are provided for the purpose of interpretation and illustration only, which may be slightly different from the actual product. Furthermore, the specification and configuration of this product may vary according to demands. Hence, it may be different from the content of this manual. The actual product shall prevail.

The non-Sugon website information mentioned in this manual is provided for the convenience. Such website information is not a part of product materials of Sugon or a part of services provided by Sugon. Hence, Sugon will not guarantee the accuracy and availability of such website information. Users shall assume the risk of using such website by themselves.

This manual is not used to indicate that Sugon guarantees its products and services expressly or implicitly, including (but not limited to) the guarantee of the applicability, safety, merchantability and fitness for particular purposes for the product recommended in this manual. The guarantee and warranty commitment for this product and related services shall be performed in accordance with applicable agreements or the terms and conditions of the standard warranty service for this product. Sugon shall not be liable for any damage caused by your use of or failure to use this product to the fullest extent permitted by laws and regulations (including, but not limited to, the direct or indirect personal injury, loss of business profits, service interruption, loss of business information or any other losses).

Sugon shall not guarantee the reliability of using the accompanying software for other products, using the non-accompanying software or other software not the proprietary software certificated and recommended by Sugon for this product.

Sugon has collated and checked this manual carefully, but it will not guarantee no errors and omissions are contained in this manual. In order to provide better services, Sugon may improve or change the product software and hardware described in this manual and the content of this manual without prior notice. If you find any discrepancy between this product and this manual when you use this product, or you want to obtain the latest information or have any question and idea, welcome to call 400-810-0466 or access the service website of Sugon www.sugon.com for the consultation.

Trademark and Copyright

"SUGON" and its icon are the trademark or registered trademark of DAWNING INFORMATION INDUSTRY CO., LTD.

"SUGON" and its icon are the trademark or registered trademark of DAWNING INFORMATION INDUSTRY CO., LTD. "DAWNING INFORMATION INDUSTRY CO., LTD" is hereinafter referred to as "Sugon".

"Intel" and "Xeon" icons are the registered trademarks of Intel.

"Microsoft", "Windows", "Windows Server" and "Windows Server System" are the trademarks or registered trademarks of Microsoft.

Other products, logos and trademarks which are mentioned in this manual but not listed above may also be trademarks or registered trademarks of other companies, and are owned by their respective companies, other organizations or individuals.

The accompanying software described in this user's manual is provided according to the terms and conditions of the end user license agreement, and can only be used and reproduced in accordance with the provisions of the end user license agreement.

Copyright © 2013 DAWNING INFORMATION INDUSTRY CO., LTD. All rights reserved.

This manual is protected by the copyright laws and regulations, and all or any part of this manual shall not be reproduced, copied, deleted or compiled into the machine-readable format in any way without the prior written authorization of Sugon, or stored in the retrieval system in any form, or transmitted over the wired or wireless network, or translated into any text in any way.

Operating Instruction for Power Supply

Switch on power supply for servers

To switch on the power supply for servers, please press the "ON/OFF" button.

Switch off power supply for servers

1. Backup the server data.
2. Shut down the operating system in accordance with the instruction of the operating system document.
(If the operating system puts the server in standby mode automatically, skip the next step.)
3. Press the "ON/OFF" button to put the server in the standby mode. When the server activates the Wait for Power mode, the system power LED indicator will change to red.
4. Unplug all power cords. At present, the system is in the Power-off status.

Requirement for Power Supply

This equipment shall be installed in accordance with the local or regional electrical regulations on the installation of information technology equipment, and the installation procedure shall be completed by the recognized electrical engineer. The equipment is designed elaborately and can operate in the installation environment that complies with the national power supply specification. For the power supply rating of relevant options, please refer to the product rating label or the accompanying user document of the option.

When more than one server are installed, other power distribution equipment may be needed to supply the power for all equipment safely. Please observe the following guidelines:

- Balance the server power supply load between the available AC power supply branch circuits.
- The total AC current load of the system is not allowed to exceed 80 percent of the AC current rating for the branch circuit.
- Do not use the ordinary power wiring board to connect with this equipment.
- The server is powered by the separate circuit.

Requirements for Electrical Grounding

The server shall be grounded properly to make it operates normally and ensure safety. This equipment shall be installed in accordance with the following requirements: Any regional or national/local electrical connection procedure, such as part 1 - 7 of IEC rules 364. Furthermore, it is necessary for you to ensure that all power distribution equipment used during the installation (such as the branch connection and socket) is of the listed or certificated ground type equipment.

For several servers connecting to the same power supply are needed to lead a large amount of electric current into underground, Sugon suggests the used PDU is connected to the branch circuit of buildings fixedly or equipped with one non-detachable wire which is connected with the industrial plug. All plugs which comply with the IEC 60309 standard shall be considered as applicable plugs. It is not suggested to use the ordinary power wiring board to connect with this server.

Electrostatic Discharge

Electrostatic Discharge Prevention

In order to prevent from damaging the system, it is necessary to take necessary precautions when you install the system or take out/put in the component. The static electricity discharged by fingers or other conductors may damage the main board or other electrostatic sensitive equipment. The electrostatic damage will shorten the expected service life of above-mentioned equipment. To prevent the electrostatic damage, attention shall be paid to the following aspects:

- The product shall be packed in the anti-static package to prevent from touching the product by hands directly during the transportation and storage.
- Before the electrostatic sensitive components are transported to the work place which is not affected by static electricity, put them in their respective package for storage.
- Take out the equipment from their package, and do not put it down, but install it into the server directly. If you want to put down the equipment, put it back in the anti-static package. Do not put the equipment on the outer cover or metal surface of the server.
- When the equipment is still in the anti-static package, the equipment shall contact the unpainted outer metal surface of the server for 2 seconds at least. In this way, it can implement the electrostatic discharge of the anti-static package and your body.
- Minimize the movement. The movement will lead to the accumulation of static electricity around your body.
- Hold the edge or frame of the equipment, and operate the equipment carefully.
- Do not touch the welding point, pin or exposed circuit.
- Do not put the equipment in the place where other people can touch and damage it.
- When you touch the electrostatic sensitive components or devices, it is necessary to take appropriate grounding measures.
- You should take particular care when operating the equipment in cold weather. The heating system will reduce indoor humidity and increase static electricity.

Grounding Method for Electrostatic Discharge Prevention

There are several grounding methods. You can use one or more of the following methods when you take out/put in or install the electrostatic sensitive components:

- You can use the wrist strap, which is connected with the grounding work area or computer chassis by grounding wire. The wrist strap shall be scalable flexibly, and the resistance of the grounding wire shall be 10 percent of 1 Mega ohms at least. To achieve the grounding purpose, the wrist strap shall be close to the skin tightly when you put on it.
- Use the heel strap, toe strap or boot strap in the vertical work area. Tie the belt on your feet when you stand on the conductive floor or dissipative static floor mat.
- Use the conductive field maintenance tool.

- Combine with the use of dissipative static folding tool pad and portable field maintenance kit.

Dangerous Warning Statement

[Warning]

This product is of the grade A product. The product may cause the radio interference in the living environment. In this case, it may require users take practical measures to prevent the interference.

The current in the power supply, telephone and communication cable is dangerous. In order to eliminate the risk of electric shock:

- Do not connect or disconnect any cable, or install, maintain, or reconfigure this product during the lightning.
 - Connect all power cords to the power supply socket with the correct wiring and proper grounding.
 - Connect all equipment which needs to be connected to this product to the socket with the correct wiring.
 - Connect or disconnect the signal cable by one hand as far as possible.
 - Do not turn on any equipment when there is signs of fire, flood or house collapse.
 - Unless otherwise stated during the installation and configuration, disconnect the connected power cord, remote communication system, network and modem before you open the outer cover of the equipment.
-

Statement 1:

[Note]

The power control button on the equipment and the power switch the power supply will not disconnect the current of the supply equipment. The equipment may be also provided with more than one power cord. To enable the equipment to be powered off completely, ensure all power cords are disconnected with the power supply.

Statement 2:

[Note]

Do not remove the outer cover of power supply or the outer cover of any component with the following label. There is dangerous voltage, current and energy level in any component with this label. There is not any maintainable component in these components. If you suspect some component with any problem, please contact technical service personnel.

Statement 3:

[Danger]

In some cases, the high branch circuit load may cause the fire and electrical shock hazard. In order to prevent such risks, ensure that the electrical requirements of the system does not exceed the protection requirements of the branch circuit. Refer to the accompanying information of the equipment to understand the electrical specification.

Operate in the interior of power-on server.

[Warning]

When the server is powered on, the static electricity discharged into the internal components of the server may cause the server to abort abnormally, which may cause data loss. To prevent this potential problem, please always use the ESD wrist strap or other grounding systems when you operate inside the power-on server. The server (some models) supports the hot plug equipment and is designed to operate safely when the server is powered on and the outer cover is removed. Please observe the following guidelines below when you operate inside the power-on server.

- Prevent from putting on clothes with loose cuffs. Clamp the button on the cuffs of long sleeve shirt before you operate it in the server internally. Do not wear any cuff links when you operate inside the server.
- Do not let tie or scarf down into the server.
- Take off all jewelries, such as bracelet, necklace, ring and loose wrist watch.
- Take out items in shirt pocket (such as pen and pencil) which may fall into the server when you bend over the server.
- Prevent any metal items (such as paper clip, hair clip and screw) from falling into the server.

Statement 4:

In order to reduce the risk of personal injury, fire or equipment damage, the AC power supply branch circuit powered for the rack shall not be overloaded. Please consult with the electrical agency who formulates the equipment wiring and installation requirements.

Statement 5:

Use the adjustable UPS to prevent the server from being affected by the power fluctuation and temporary power outage. This equipment can prevent the hardware from being damaged by the impact of surge and peak voltage, and maintain the system in normal operation state during power failure.

Statement 6:

When you use the cable management arm component, each cable shall be kept loose to prevent from damaging the cable when taking out server from the rack.

Statement 7:

To reduce the risk of electric shock or equipment damage, attention shall be paid to the following aspects:

- Make sure to use the grounding plug of the power cord. The grounding plug can perform important safety protection function.
- Always plug the power cord into the nearby accessible grounding power socket.
- Unplug the power cord to disconnect the power supply of the equipment.
- Do not put power cord in a place where it is easy to be stepped on or squeezed by the object beside it. Special

attention shall be paid to the plug, power socket and the connection point between power line and server.

Statement.....	ii
Trademark and Copyright.....	iii
Operating Instruction for Power Supply.....	iv
Dangerous Warning Statement.....	vi
List of Figures.....	xii
List of Tables.....	xviii
1 System Overview	1
1.1 I620-G20	1
1.2 Product Features.....	1
1.3 Product Specification.....	3
1.3.1 Technical Specification	3
1.3.2 Application Environment of Products.....	4
Table 1-3 Operation environment of products	4
2 Architecture and Installation	4
2.1 Product components	4
2.1.1 Front panel component.....	5
2.1.2 Rear panel component.....	8
2.2 Disassembly of product chassis and main components	9
2.2.1 Preparation prior to power on	9
2.2.2 Steps for uncovering server	10
2.2.3 Removing CPU	11
2.2.4 Removal steps of CPU heat radiators	14
2.2.5 Memory disassembly steps.....	15
2.2.6 Hard disk disassembly steps	17
2.2.7 Power disassembly steps.....	18

2.2.8	Disassembly steps of expansion cards	19
2.2.9	Disassembly steps of fan.....	20
2.2.10	Installation instruction of guide components.....	21
3	Product configuration	27
3.1	LCD module	27
3.1.1	Typical application	27
3.1.2	Function description	27
3.1.3	Inquiry and operation of system-related information	28
3.2	Eliminate CMOS jumper setting	32
3.3	BIOS setup	33
3.3.1	System BIOS setup method.....	33
3.3.2	Main menu	34
3.3.3	Advanced menu	35
3.3.4	Chipset menu	44
3.3.5	Server Mgmt menu	61
3.3.6	Security menu	69
3.3.7	Boot menu.....	70
3.3.8	Save & Exit menu	71
3.4	BMC configuration	71
3.4.1	Dashboard	73
3.4.2	FRU & DMI.....	75
3.4.3	Server Health.....	78
3.4.4	Component Information	82
3.4.5	Configuration	88
3.4.6	Remote Control	107
3.4.7	Auto Video Recording	115
3.4.8	Maintenance	116
3.4.9	Firmware Update	118
4	OS installation guide	120

4.1	Windows 2008 Enterprise Server R2 SP1 64bit	120
4.2	Red Hat Enterprise Linux AS 6 Update 2 X86_64	120
5	FAQ of products	122
Appendix I	Abbreviations	122
Appendix II	POST code check point of LCD.....	124
Appendix III	RAID configuration description of onboard hard disk controller.....	131

List of Figures

Figure 2-1 Schematic diagram of front panel.....	11
Figure 2-2 Schematic diagram of reset key	12
Figure 2-3 Schematic diagram of hard disk indicator	12
Figure 2-4 Rear view of product.....	14
Figure 2-5 Uncover chassis.....	16
Figure 2-6 Take air director and line shielding cover	16
Figure 2-7 CPU Socket schematic diagram.....	17
Figure 2-8 Schematic diagram for opening CPU locking rod	17
Figure 2-9 Schematic diagram for opening CPU protective cover	17
Figure 2-10 CPU installation	18
Figure 2-11 CPU locking	18
Figure 2-12 Install CPU heat radiator.....	19
Figure 2-13 Schematic diagram of memory installation.....	21
Figure 2-14 Lock hard disk box fastener.....	21
Figure 2-15 Pull out hard disk box	21
Figure 2-16 Fix hard disk.....	22
Figure 2-17 Press locking buckle	22
Figure 2-18 Plug out the power module.....	22
Figure 2-19 Installation of expansion card	23
Figure 2-20 Fan pull-out schematic diagram	24
Figure 2-21 Guide components.....	24
Figure 2-22 Fixing position of front support of sliding rail	25
Figure 2-23 Pull out internal guide	25
Figure 2-24 Installation method of internal rail.....	26
Figure 2-25 Install external guide to cabinet upright post.....	26
Figure 2-26 Upright post position diagram.....	27
Figure 2-27 Install machine onto external rail.....	27
Figure 2-28 Lock external guide.....	28
Figure 2-29 Install the chassis in place and lock it	28
Figure 2-30 Unlock chassis	29
Figure 3-1 LCD display module layout diagram.....	29
Figure 3-2 LCD principle flowchart.....	31
Figure 3-3 Initial interface.....	31
Figure 3-4 Display mode of fan status	32
Figure 3-5 Display mode of CPU temperature status.....	32

Figure 3-6 BMC IP address format	33
Figure 3-7 System status	33
Figure 3-8 Main menu interface	36
Figure 3-9 Advanced menu interface	37
Figure 3-10 Benchmark Recommendation Setting menu interface.....	38
Figure 3-11 ACPI Settings interface	38
Figure 3-12 Wakeup Event Setup interface	39
Figure 3-13 Serial Port Console Redirection interface	40
Figure 3-14 (COM0) Console Redirection Settings interface	40
Figure 3-15 (EMS) Console Redirection Settings configuration interface	41
Figure 3-16 PCI Subsystem Settings configuration interface	42
Figure 3-17 Network Stack Configuration interface	43
Figure 3-18 CSM Configuration interface	43
Figure 3-19 H/W Monitor menu interface.....	45
Figure 3-20 Chipset menu interface.....	46
Figure 3-21 Processor Configuration menu interface.....	47
Figure 3-22 Advanced Power Management Configuration menu interface.....	49
Figure 3-23 CPU P State Control menu interface.....	50
Figure 3-24 CPU C State Control menu interface	50
Figure 3-25 Common RefCode Configuration menu interface	51
Figure 3-26 QPI Configuration menu interface	52
Figure 3-27 QPI General Configuration menu interface	52
Figure 3-28 QPI Status menu interface	53
Figure 3-29 Memory Configuration menu interface	53
Figure 3-30 Memory Map menu interface.....	54
Figure 3-31 Memory RAS Configuration menu interface.....	54
Figure 3-32 IIO Configuration menu interface.....	55
Figure 3-33 IOAT Configuration menu interface	55
Figure 3-34 Intel VT for Directed I/O (VT-d) menu interface.....	56
Figure 3-35 PCH Configuration menu interface.....	57
Figure 3-36 PCH Devices menu interface	57
Figure 3-37 PCH sSATA Configuration menu interface	58
Figure 3-38 PCH SATA Configuration menu interface	59
Figure 3-39 USB Configuration menu interface	59
Figure 3-40 Server Mgmt menu interface	60
Figure 3-41 System Event Log menu interface.....	62
Figure 3-42 BMC self-test log menu interface	62

Figure 3-43 BMC Network Configuration menu interface	63
Figure 3-44 View System Event Log menu interface.....	64
Figure 3-45 BMC User Settings menu interface	64
Figure 3-46 Add User menu interface	65
Figure 3-47 Delete Users menu interface	65
Figure 3-48 Change User Settings menu interface	66
Figure 3-49 Security menu interface	67
Figure 3-50 Boot menu interface.....	67
Figure 3-51 Save & Exit menu interface	68
Figure 3-52 login interface.....	69
Figure 3-53 User entry interface	69
Figure 3-54 Management platform items	69
Figure 3-55 Device information module	70
Figure 3-56 Network information module	71
Figure 3-57 Remote console module	71
Figure 3-58 Sensor information module (part)	72
Figure 3-59 Event log module	72
Figure 3-60 FRU&DMI sub-menu	73
Figure 3-61 FRU information interface.....	73
Figure 3-62 DMI information interface.....	74
Figure 3-63 Server Health submenu	75
Figure 3-64 Sensor reading main interface.....	75
Figure 3-65 Sensor list area (part)	76
Figure 3-66 Detailed sensor information area.....	76
Figure 3-67 Threshold setup interface	77
Figure 3-68 Sensor event statistics diagram.....	77
Figure 3-69 Time log interface	77
Figure 3-70 System Log interface	78
Figure 3-71 Audit Log interface	78
Figure 3-72 BSOD Screen interface	79
Figure 3-73 CPU information display	79
Figure 3-74 Memory information interface	80
Figure 3-75 Onboard Hard Disk information interface	80
Figure 3-76 Hard Disk information interface	81
Figure 3-77 PCIe Device information interface	81
Figure 3-78 PSU information interface.....	82
Figure 3-79 FAN information interface	82

Figure 3-80 Onboard NIC information interface.....	83
Figure 3-81 Expander NIC information interface	83
Figure 3-82 Configuration submenu interface.....	84
Figure 3-83 Active directory interface.....	84
Figure 3-84 Advanced active directory setup interface.....	84
Figure 3-85 Role group addition interface.....	85
Figure 3-86 Advanced Audit Log interface	86
Figure 3-87 DNS interface.....	87
Figure 3-88 LDAP/E-Directory interface	88
Figure 3-89 Advanced LDAP setup interface.....	88
Figure 3-90 Mouse mode interface	89
Figure 3-91 Management network setup interface	90
Figure 3-92 Network bonding setup interface.....	90
Figure 3-93 NTP setup interface	91
Figure 3-94 PEF management interface.....	91
Figure 3-95 Event Filter addition interface -1.....	92
Figure 3-96 Event Filter addition interface -2.....	92
Figure 3-97 Figure 3-97Event Filter addition interface -3.....	93
Figure 3-98 Figure 3-98 Event Filter addition interface -4.....	93
Figure 3-99 Alert Policy addition item interface.....	94
Figure 3-100 LAN Destination addition item interface	94
Figure 3-101 RADIUS interface	95
Figure 3-102 Remote conference interface	95
Figure 3-103 SMTP interface.....	96
Figure 3-104 SSL authentication configuration interface.....	97
Figure 3-105 Generate SSL item interface	98
Figure 3-106 View SSL item interface	98
Figure 3-107 System and audit log setup interface	98
Figure 3-108 System firewall setup interface.....	99
Figure 3-109 IP address policy addition interface.....	99
Figure 3-110 Port policy addition interface.....	100
Figure 3-111 Advanced setup interface.....	100
Figure 3-112 Users interface	100
Figure 3-113 User addition interface	101
Figure 3-114 Virtual Media interface	102
Figure 3-115 User lock setup interface	102
Figure 3-116 Remote control submenu.....	102

Figure 3-117 Console Redirection interface.....	102
Figure 3-118 Redirection interface	103
Figure 3-119 Virtual media mounting interface	103
Figure 3-120 Video submenu	104
Figure 3-121 Keyboard submenu.....	105
Figure 3-122 Keyboard Layout submenu.....	105
Figure 3-123 Video Record submenu	105
Figure 3-124 Video recording setup interface.....	106
Figure 3-125 Power submenu.....	106
Figure 3-126 Power Control and Status.....	107
Figure 3-127 Java SOL interface	107
Figure 3-128 Serial port redirection setup interface.....	108
Figure 3-129 Session submenu	108
Figure 3-130 ID control interface.....	108
Figure 3-131 Power button setup interface.....	109
Figure 3-132 Fan policy setup interface.....	109
Figure 3-133 BIOS first start item selection interface	109
Figure 3-134 Automated video recording submenu.....	110
Figure 3-135 Trigger condition setup interface	110
Figure 3-136 Recorded video list interface	110
Figure 3-137 Maintenance submenu	111
Figure 3-138 Setup interface for keeping existing configuration	111
Figure 3-139 Factory setting recovery setup interface	111
Figure 3-140 Firmware Update submenu	112
Figure 3-141 BMC firmware upgrade interface.....	112
Figure 3-142 Selection interface of BMC firmware upgrade and refreshing module	112
Figure 3-143 BIOS firmware refreshing interface	113
Figure 3-144 BIOS firmware refreshing alert interface	113
Figure 0-1 POST prompt interface.....	125
Figure 0-2 RAID management interface	125
Figure 0-3 Controller menu interface	126
Figure 0-4 RAID creation interface.....	126
Figure 0-5 Hard disk selection	127
Figure 0-6 Advanced setup interface	127
Figure 0-7 Delete Virtual Drive.....	128
Figure 0-8 Delete Drive Group	128
Figure 0-9 Clear RAID configuration information	129

List of Tables

Table 1-1 I620-G20 parameter table (for four device types)	7
Table 1-2 Model parameter table of different disks	8
Table 1-3 Operation environment of products	9
Table 2-1 Description of key functions	11
Table 2-2 Description of front panel LED indicator function.....	11
Table 2-3 Description of hard disk rear board indicator	13
Table 2-4 Interface description of rear panel.....	14
Table 2-5 Memory installation rule table①.....	19
Table 3-1 Interface description	29
Table 3-2 Failure information report	34
Table 3-3 CMOS jumper clearing description	34
Table 3-4 Description of control key	35
Table 3-5 Description of Main interface parameters	36
Table 3-6 Description of Advanced interface parameters	37
Table 3-7 Description of Benchmark Recommendation Setting interface parameter.....	38
Table 3-8 Description of ACPI Settings interface parameters.....	39
Table 3-9 Description of Wakeup Event Setup interface parameters	39
Table 3-10 Description of Serial Port Console Redirection interface.....	40
Table 3-11 Description of (COM0) Console Redirection Settings.....	40
Table 3-12 Description of (EMS) Console Redirection Settings configuration interface	41
Table 3-13 Description of PCI Subsystem Settings configuration interface	42
Table 3-14 Description of network Stack Configuration interface	43
Table 3-15 Description of CSM Configuration interface.....	43
Table 3-16 Description of H/W Monitor interface parameter.....	45
Table 3-17 Description of Chipset interface parameter.....	46
Table 3-18 Description of Processor Configuration interface parameters	47
Table 3-19 Description of Advanced Power Management Configuration interface parameters....	49
Table 3-20 Description of CPU P State Control interface parameter.....	50
Table 3-21 Description of CPU C State Control interface parameter	50
Table 3-22 Description of Common RefCode Configuration interface parameter	51
Table 3-23 Description of QPI Configuration interface parameter	52
Table 3-24 Description of QPI General Configuration interface parameter	52
Table 3-25 Description of Memory Configuration interface parameter	53
Table 3-26 Description of Memory Map interface parameter.....	54

Table 3-27 Description of memory RAS Configuration interface parameter.....	54
Table 3-28 Description of IIO Configuration interface parameter	55
Table 3-29 Description of IOAT Configuration interface parameter	55
Table 3-30 Description of Intel VT for Directed I/O (VT-d) interface parameter.....	56
Table 3-31 Description of PCH Configuration interface parameter.....	57
Table 3-32 Description of PCH Devices interface parameter	57
Table 3-33 Description of PCH sSATA Configuration interface parameter	58
Table 3-34 Description of PCH SATA Configuration interface parameter	59
Table 3-35 Description of Server Mgmt interface parameter	60
Table 3-36 Interface parameter description of Server Mgmt	60
Table 3-37 Description of system Event Log interface parameter	62
Table 3-38 Description of BMC self-test log interface parameter	62
Table 3-39 Description of BMC Network Configuration interface parameter.....	63
Table 3-40 Description of BMC User Settings interface parameter	64
Table 3-41 Description of BMC User Settings interface parameter	65
Table 3-42 Description of Delete User interface parameter.....	65
Table 3-43 Description of Change User Settings interface parameter	66
Table 3-44 Description of security interface parameter	67
Table 3-45 Description of Boot interface parameter	67
Table 3-46 Description of Save & Exit interface parameter	68
Table 3-47 Description of management platform	69
Table 3-48 Description of basic information	73
Table 3-49 Description of Chassis Information	73
Table 3-50 Description of Board Information.....	73
Table 3-51 Description of Product Information.....	74
Table 3-52 Description of BIOS Information.....	74
Table 3-53 Description of System Information	74
Table 3-54 Description of Board Information.....	74
Table 3-55 Description of temperature sensor threshold.....	76
Table 3-56 Description of CPU information.....	79
Table 3-57 Description of Memory information	80
Table 3-58 Description of Onboard Hard Disk information	80
Table 3-59 Description of Hard Disk information.....	81
Table 3-60 Description of PCIe Device information	81
Table 3-61 Description of PSU information	82
Table 3-62 Description of FAN information	82
Table 3-63 Description of Onboard NIC information	83

Table 3-64 Description of Expander NIC information.....	83
Table 3-65 Description of BIOS Information.....	84
Table 3-66 Description of role group addition interface	85
Table 3-67 Description of Advanced auditing log setup interface	86
Table 3-68 Description of DNS setup interface	87
Table 3-69 Description of advanced LDAP setup interface	88
Table 3-70 Network setup interface information	90
Table 3-71 Information description of Event Filter item information.....	92
Table 3-72 Information description of Alert Policy item information.....	92
Table 3-73 Information description of LAN Destination item information.....	91
Table 3-74 Description of Event Filter adding items	93
Table 3-75 Description of Alert Policy adding items.....	94
Table 3-76 Description of LAN Destination adding items.....	94
Table 3-77 Description of RADIUS interface information.....	95
Table 3-78 Description of Remote Session interface information.....	96
Table 3-79 Description of SMTP interface information	96
Table 3-80 Description of Generate SSL interface information.....	98
Table 3-81 Description of system and audit log setup interface information	99
Table 3-82 Description of user information item addition.....	101
Table 3-83 Description of Power option	107
Table 3-84 Description of serial port redirection setup interface.....	108
Table 3-85 Description of trigger condition.....	110

1 System Overview

The following sections provide detailed information about the I620-G20 system.

1.1 I620-G20

- I620-G20 server is a high-performance 2-way server, which is developed by Sugon based on the latest Intel Grantley-EP platform. This server supports the latest Intel Haswell CPU, which is made by using 22nm processor and supports 4-way DDR4 memory. Each channel can support up to 3 memory DIMM slots, maximum 2133MHz, higher QPI link rate, more CPU cores, and maximum 18 physical cores. The server integrates 40 Lanes PCIe 3.0.
- The I620-G20 server supports 8, 12, 16 and 24 disks and maximum 24 2.5 inch SATA/SAS hard disk, which can satisfy the administrative server requirements of general users and can be used as the storage server for massive storage. More PCI-E slots, brand-new horizontal card and high-rate PCI-E bus enable users to realize easy expansion.
- The I620-G20 server is very applicable to the industries such as Internet, photo-electricity, public security, telecommunication and power, which require stricter energy consumption ratio and reliability.

1.2 Product Features

Versatile Chassis Bay

- The chassis is divided into 8-disk chassis, 12-disk chassis, 16-disk chassis and 24-disk chassis.
- Optionally support two 2.5 inch built-in hard disks (non-hot plug) and be compatible to SATA/SAS/SSD hard disks.
- Optionally support 2 or 4 rear disk slots and be compatible to different hard disks such as SATA/SAS/SSD;
- The monitoring functions based on the LCM monitoring screen are added for 8 and 16 disk slots. The monitoring screen supports to display the SUGON Logo, CPU model and BMC IP address and inquire CPU temperature, fan rotation speed and current operation power. When a server fails to boot, the server can display corresponding Debug Code. A user can quickly locate the problem by inquiring or providing Debug Code and quickly solve the server failure.
- The power specification is completely upgraded to CRPS specification. This uniform industrial specification enables the product quality to keep abreast with the international level. The power meets the requirements of 80Plus platinum power. The conversion efficiency reaches 94%, so it can save energy and protect the environment. The standard single-power module is adapted to the user's single power requirement. One power redundant module is optionally configured to upgrade to 1+1 redundant power. In addition, when the user selects to install GPU, the server optionally supports 1200W high-power CRPS redundant power powered by GPU.

High performance

- The latest Intel E5-2600 v3 processor is used to provide higher performance for different user applications. Compared to older products, Intel Xeon E5-2600 v3 processors are improved more, including integrated PCI-E controller inside the processor. The PCI-E bus is upgraded to 3.0 standards and extremely improves the expansion performance. More and quicker QPI buses are used between processors to improve the collaboration efficiency between CPU much.
- The server supports 1866/2133 MHz DDR4 memory. Each CPU integrates 4-way memory controller. Compared to older product, the memory bandwidth performance can be improved by maximum 40% and the memory power consumption will reduce by 25%.

High reliability

- Provide advanced memory error tolerance function.
- Provide optional RAID configuration, support online RAID array recovery, and secure data in case of a hard disk failure.
- Support multi-network card redundancy, which can share the network traffic when the system operates normally. When one network card fails, the shared work will be automatically switched to other network cards.
- The front panel is designed with the monitoring screen, which can monitor the system hardware and display the system information and operation state of the hardware such as CPU and fan.
- Standard 1+1 redundant power, which can avoid instantaneous power failure and provide the users with more stable and reliable system power.
- The server support 6 PCI-E 3.0 expansion slots and is designed with the horizontal slot. The server supports full-height cards such as GPU and provides high scalability.

High Manageability

- Optional intelligent hardware monitoring system, which displays the operation states such as internal temperature, fan rotary speed and DC power voltage, and can automatically record the time and log information for failure analysis when the host stops operation due to a failure.
- Support intelligent and dynamic adjustment of fan's rotating speed, which can dynamically adjust the fan's rotating speed with the system temperature and effectively reduce the system noises and power consumption.
- Be configured with front panel touch screen for easy management.

Easy maintenance

Integrate iKVM function, which can provide remote operation and maintenance, provide failure indication function, and effectively reduce crash risk of users.

1.3 Product Specification

1.3.1 Technical Specification

Table 1-1 I620-G20 Parameter Table

Parameter name	Specification
Processor	Support Intel Xeon E5-2600v3 multi-core processor, high-speed QPI interconnection bus (9.6/8.0/6.4 GT/s, depending on different CPU models), high-capacity L3 cache (15/20/25/30/35 MB, depending on CPU models).
Memory	24 memory slots Support DDR4 2133/1866 ECC memory (the work frequency will vary with CPU and memory configuration) The memory can expand to maximum 1.5TB
Memory controller	Integrate 8-port SATA hard disk controller and support RAID 0, 1, 5 and 10 Optionally integrate 8-port SAS RAID card and support RAID 0/1/5/6/10/50/60
Hard disk scheme	Four optional hard disk schemes for four models: 8-disk model can support maximum 8 3.5 inch or 2.5 inch hot-plug SAS/SATA hard disk 16-disk model can support maximum 16 2.5 inch hot-plug SAS/SATA hard disk 12-disk model can support maximum 12 3.5 inch or 2.5 inch hot-plug SAS/SATA hard disk 24-disk model can support maximum 24 2.5 inch hot-plug SAS/SATA hard disk All models should support mixed insertion of SAS/SATA hot-plug and optional 4 rear hot-plug 2.5 inch SATA/SAS hard disk or SSD hard disk
Display system	Graphic controller integrating BMC chip
CD ROM	Optional SATA ultra-thin DVD-RW CD ROM or USB DVD-RW CD ROM
Network card	Integrate double 1000M network card and one management network interface (independent).
Expansion slot	Support maximum 8 PCI-E expansion slots Optionally support horizontal Riser expansion card and maximum 5 full-height expansion cards; Optionally install high-performance GPU (with high-power power supply)
External device interface	1 RJ-45 management interface in the rear of the chassis 4 USB 2.0 interfaces, including 2 interfaces in the rear of the chassis and 2 interfaces at the front of the chassis 1 VGA interface in the rear of the chassis and optional front VGA 1 serial port in the rear of the chassis
Chassis size	87.8mm(height)x 448mm(width)x794.4mm(depth)
Power voltage	220V 50Hz
Heat dissipation system	4 intelligent speed-adjusting and hot-plug system fans
Compatible OS	Windows Server 2008 Enterprise Edition R2 SP164bit Red hat Enterprise Linux 6.2 for Intel EM64T SuSE Linux Enterprise Server 11 SP2 for Intel EM64T

Table 1-2 Model Parameter Table of Different hard disk bays

Disk number	Type of disk	Monitoring screen	Power supply	Built-in CD
-------------	--------------	-------------------	--------------	-------------

8 disks	3.5 inch (compatible to 2.5 inch)	Optional	Support CRPS 550W, 800W and 1200W power module Support 1+1 redundancy	Support
12 disks	3.5 inch (compatible to 2.5 inch)	Not supported	Support CRPS 550W, 800W and 1200W power module Support 1+1 redundancy	Not support
16 disks	2.5 inch	Optional	Support CRPS 550W, 800W and 1200W power module Support 1+1 redundancy	Support
24 disks	2.5 inch	Not support	Support CRPS 550W, 800W and 1200W power module Support 1+1 redundancy	Not support

Note: Sugon reserves the right to change the configuration without the prior notice to users.

1.3.2 Application Environment of Products

Table 1-3 Operation environment of products

Parameter	Operation indicator
Operation space	2U
Operation temperature	10°C-35°C (50°F -95°F)
Operation humidity	35%-80% RH
Transportation and storage temperature	-40°C-55°C (-40°F -131°F)
Transportation and storage humidity	20%-93% RH(40°C)
Elevation	Less than or equal to 3000m
Falling height in packing and transportation	Less than or equal to 600mm


2 Architecture and Installation

This chapter describes the overall system architecture and installation for the I620-G20. You can know basic structure principle and correct wiring mode of I620-G20 server and notices for safe server operation in this chapter. To carefully read this chapter, it will contribute to safe and stable operation of the I620-G20 server much.

2.1 Product components


2.1.1 Front panel component

1. USB 2. Power Button 3. ID Button 4. Reset button 5. HDD LED
 6. Warning LED 7. NIC1 8. NIC2 9. LCM 10. Optical Disc Drive
 11. Hard Disk Drive 12. Unlock Clips




Front view of 8 HDD bays of the I620-G20

1. Power Button 2. NIC1 3. NIC2 4. Warning LED 5. ID Button 6. Unlock Clips
 7. Hard Disk Drive 8. USB




Front view of 12 HDD bays of the I620-G20

1. Unlock Clips 2. Hard Disk Drive 3. Optical Disc Drive 4. LCM 5. USB
 6. Power Button 7. ID Button 8. Reset Button 9. Warning LED 10. NIC4
 11. NIC3 12. NIC2 13. NIC1



Front view of 16 HDD bays of the I620-G20

1. Power Button 2. NIC1 3. NIC2 4. Warning LED 5. ID Button 6. Unlock Clips
 7. Hard Disk Drive 8. USB Port



Front view of 24 HDD bays of the I620-G20

Figure 2-1 Front view of I620-G20

Table 2-1 Description of key functions







Key	Symbol	Function description
Power button		Click power button: power on or send power off command to OS Hold power button: forcefully power off
ID button	ID	Turn on or turn off blue ID lamp for server identification
Reset key	Rst	To press Reset key, the server will restart

Table 2-2 Description of front panel LED indicator function

LED indicator	Symbol	Function description
Hard disk indicator		On: the hard disk works normally; Off: hard disk failure or no hard disk
System failure indicator		Off: the server system fails or is exceptional; On: the server works normally
ID indicator		It is installed on ID key. The blue indicator is on. The user can recognize this server mark.
NIC1/NIC2 indicator		On: the onboard LAN works; Off: the onboard LAN is inactive;
Power indicator		It is installed on the power button. On: the server is in operation; Off: the server does not start

Operations on server reset button

The position of the reset button on the server is shown as the figure 2-2. When a user resets the server, he can press the reset button by using the nib or sharp objects (shown as the figure) and restart the server.




Figure 2-2 Schematic diagram of reset key

Description of hard disk indicator

Each hard disk is configured with two LED indicators, including active indicator and Status indicator, shown as the figure 2-3.




Figure 2-3 Schematic diagram of hard disk indicator

The Active indicator is the green monochrome LED indicator. The Status indicator is the green/amber double-color LED indicator. By observing the status change of two indicators, you can get the operation status of the hard disk, shown as the table 2-3.

Table 2-3 Description of hard disk rear board indicator

Active indicator	Status indicator	Hard disk status
Off	Off	The hard disk does not boot
On	Off	The hard disk do not execute read operation and is under the idle state
Flicker	Off	The hard disk is operating and is under read/write status
On	Green indicator is on	The hard disk controller management interface shows Locate operation in execution
Flicker	Amber indicator slowly flickers (1Hz)	The hard disk is executing RAID reestablishment
On	The amber indicator is on	A hard disk in reconstructed RAID group is removed

2.1.2 Rear panel component

The rear panel view of the server will vary with the configuration of IOM module, Riser card and rear hard disk, shown as the figure 2-4.









Figure 2-4 Rear view of product

Table 2-4 Interface description of rear panel

Symbol	Description
	USB interface
	VGA interface (video interface)
	COM interface (serial port)
	Network interface/BMS management interface
	AC input end

2.2 Disassembly of product chassis and main components

This section will introduce disassembly steps and notices of I620-G20 server to you. Please disassemble the I620-G20 server according to the requirements.

Note: All images are only for reference, refer to the material objects.

2.2.1 Preparation prior to power on

Open the server packing box

- Before unpacking, make sure to check if the chassis package is damaged. If any damage occurs, please consult the delivery person, fill related cords, and keep the delivery certificates.
- Unpack the product, check the list of accompanied component and determine if the accompanied components are complete. If any component is missing, please confirm it together with the filed engineers. First unpack plastic bag outside the packing box, place it at the proper site for keeping, lift the host from the packing box, remove the plastic bag for internal packing, and carefully and stably place the host at the proper site.

Server placement

- Please select a proper placement site for the server, which is clean, well ventilated and is remote from the heat source and strong electromagnetic area, provide enough operation space for easily plugging off the power cable from the power and power socket, and ensure good power grounding.

Sever wiring

After the server is placed under proper conditions, you should disassemble fitting box, take out the keyboard, mouse and power cable, and connect the server.

- Connect the keyboard and mouse to the USB interface.

[Notice] Do not plug in/off or forcefully plug in/off keyboard and mouse wire under live state.

Otherwise, it will damage the interface damage of the server host.

-
- Connect the display, match the display signal cable properly according to the interface shape, slightly insert it, and lock fixing screws on both sides.
 - Connect the network cable with standard RJ45 interface and insert it into the interface with NIC text on the I/O rear board;
 - Connect the standard 220V input power cable, use the three-wire interface with secure grounding and confirm that the general power is disconnected before the power cable is inserted.
 - Finally check if different parts are wired correctly. After it is fastened, to turn on the general power switch, you will enter the brand-new 64-bit computer world.

2.2.2 Steps for uncovering server

Step 1: Pull the chassis latch, lift it upward, and take the up cover of the front half part of the chassis.




Figure 2-5 Open cover from chassis

Step 2: Anticlockwise rotate the rear fixing screws of the chassis, push the up cover plate back, and take off the rear cover.




Figure 2-5 Take off the cover

Step 3: Take off the line shielding cover and air director.




Figure 2-6 Take off air director and line shielding cover

2.2.3 Removing CPU

【Notice】 When the CPU is installed, please notice the following items:

- Take and place it carefully in case of installation. Notice that CPU should not slide and damage the pin inside the CPU slot on the mainboard. Carefully check CPU slot of the mainboard in case of installation and check damage. If the pin inside CPU is damaged, please contact us in time.
- If the server starts without installed heat radiator, it will easily lead to CPU over-heat and CPU burning and bring unnecessary loss.

Step 1: First find the CPU slot on the mainboard, shown as the figure 2-7.




Figure 2-7 CPU Socket schematic diagram

Step 2: Loosen CPU locking rod by referring to the figure 2-8.




Figure 2-8 Schematic diagram for opening CPU locking rod

Step 3: Shown as the figure 2-9, please loosen the locking rod and uncover the protective cover in the arrow direction in the figure.




Figure 2-9 Schematic diagram for opening CPU protective cover

Step 4: Shown as the 2-10, place CPU into the CPU slot of the mainboard and notice mapping between CPU Keys and Socket Keys.




Figure 2-10 CPU installation

Step 5: Close the up cover of CPU Socket and snap the locking rod in place, shown as the figure 2-11.

Step 6: Repeat the above steps and install additional CPU.




Figure 2-11 CPU locking

Note: Before the CPU is disassembled, first remove the heat radiator on CPU and then CPU

2.2.4 Removal steps of CPU heat radiators

【Notice】 Before CPU heat radiator is installed, check if the heat radiator has the silicon glue. If no silicon glue is available or the silicon glue is air drying, it should be painted again.

Step 1: Ensure that CPU is installed into CPU slot.

Step 2: Place the screw holes at four corners of the heat radiator and screw holes of CPU slot at the corresponding positions.

Step 3: Screw up the screws and fix and install CPU heat radiators.




Figure 2-12 Install CPU heat radiator

Note: the disassembly steps are reverse.

2.2.5 Memory disassembly steps

Table 2-5 Memory installation rule table①

	Installation of single CPU (CPU0 only)											
Quantity of memory Installed	1	2	3	4	6	8	9	12				
CPU1_DIMMA0	√	√	√	√	√	√	√	√				
CPU1_DIMMA1					√	√	√	√				
CPU1_DIMMA2							√	√				
CPU1_DIMMB0			√	√	√	√	√	√				
CPU1_DIMMB1					√	√	√	√				
CPU1_DIMMB2							√	√				
CPU1_DIMMC0		√	√	√	√	√	√	√				
CPU1_DIMMC1					√	√	√	√				
CPU1_DIMMC2							√	√				
CPU1_DIMMD0				√		√		√				
CPU1_DIMMD1						√		√				
CPU1_DIMMD2								√				

Memory installation rule table②

	Installation of double CPU (CPU0 and CPU1)											
Quantity of memory Installed	1	2	4	6	8	10	12	14	16	18	21	24
CPU1_DIMM_A0	√	√	√	√	√	√	√	√	√	√	√	√
CPU1_DIMM_A1						√	√	√	√	√	√	√
CPU1_DIMM_A1										√	√	√
CPU1_DIMM_B0				√	√	√	√	√	√	√	√	√
CPU1_DIMM_B1							√	√	√	√	√	√
CPU1_DIMM_B2										√	√	√
CPU1_DIMM_C0			√	√	√	√	√	√	√	√	√	√
CPU1_DIMM_C1							√	√	√	√	√	√

CPU1_DIMM_C2										√	√	√
CPU1_DIMM_D0					√	√		√	√		√	√
CPU1_DIMM_D1								√	√		√	√
CPU1_DIMM_D2											√	√
CPU1_DIMM_E0		√	√	√	√	√	√	√	√	√	√	√
CPU1_DIMM_E1						√	√	√	√	√	√	√
CPU1_DIMM_E2										√	√	√
CPU1_DIMM_F0				√	√	√	√	√	√	√	√	√
CPU1_DIMM_F1							√	√	√	√	√	√
CPU1_DIMM_F2										√	√	√
CPU1_DIMM_G0			√	√	√	√	√		√	√	√	√
CPU1_DIMM_G1							√		√	√	√	√
CPU1_DIMM_G2										√	√	√
CPU1_DIMM_H0					√	√				√	√	√
CPU1_DIMM_H1										√	√	√
CPU1_DIMM_H2										√	√	√

Note: The √ in the table indicates the installation memory of this memory slot. The blank indicates that this memory slot is not installed with the memory.

Installation method:

Step 1: Open the spanner on both sides of the memory slot;

Step 2: Align the memory with the memory slot and make the opening on the memory module mapped with the memory slot.

Step 3: Press the memory into the memory slot forcefully till locking sound of the memory spanner is heard.




Figure 2-13 Schematic diagram of memory installation

Note: the disassembly steps are reverse.

2.2.6 Hard disk disassembly steps

Step 1: Lock the sunk area at the front of the hard disk with the hand and press the front fastener of the hard disk box.




Figure 2-14 Lock hard disk box fastener

Step 2: After the tray rack is unlocked, pull the hard disk out forcefully.




Figure 2-15 Pull out hard disk box

Step 3: Shown as the figure 2-16, place the hard disk into the hard disk box and fix it around the box with the screws.




Figure 2-16 Fix hard disk

Remark: The hard disk is disassembled via the reverse steps.

2.2.7 Power disassembly steps

Disassembly of redundant power

Step 1: Press the blue locking buckle of the power module according to the direction in the following figure.




Figure 2-17 Press locking buckle

Step 2: Pull the power module drag the hook with the middle finger, extend it outward in the direction in the following figure, and take out the power module.




Figure 2-18 Plug out the power module

2.2.8 Disassembly steps of expansion cards

Step 1: Ensure one dummy wafer on any empty expansion slot. One open expansion slot without

dummy wafer will destruct the EMI (electromagnetic disturbance feature) integrity and reduce the system heat dissipation effect, so it may lead to over-heat, affect system performance or lead to component damage.

Step 2 Take off PCIE adapter, shown as the figure 2-19.

Step 3: Screw off the fixing screw of the dummy wafer of the expansion card and take off the dummy wafer on the expansion card;

Step 4: Horizontally insert the PCIE expansion card and fix it with the screws;

Note: The disassemble steps are performed reversely.




Figure 2-19 Installation of expansion card

2.2.9 Disassembly steps of fan

Fan installation

Step 1: Align the terminal of the hotspare fan module with the internal interface of the fan cabin.

Step 2: Insert the fan module downward till the locking sound of the shell splinter is heard, which indicates that the fan is installed.

Fan disassembly

Step 1: Insert the hand into the sunk area on both sides of the fan and press the fan fastener in the direction in the number ① in the figure.

Step 2: Pull out the fan in the direction of the number ② in the figure.




Figure 2-20 Fan pull-out schematic diagram

2.2.10 Installation instruction of guide components

Take out the guide components and pull out the internal guide.

Guide components

Shown as the following figure, A is the external guide and support component. B is the internal guide. C is the latch at the closing position of the internal guide. D is the locking plate at the opening position of the sliding rail. E is the screw to fix the external guide support and cabinet (specification: # 8-32×1/2, number: 4). F is the screw to fix the internal guide and chassis (specification: #6-32X5, number: 2).




Figure 2-21 Guide components

Fixing position of front support of sliding rail

Shown as the figure 2-22, the fixing position of the front support of the sliding rail is selected according to the actual design size of the chassis. The front support is adjusted within 0-24mm. Total four fixing positions are available. The gap between two adjacent fixing positions is 8mm.




Figure 2-22 Fixing position of front support of sliding rail

Pull out internal guide

Pull out the internal guide till the internal guide is self-locked (shown as the following figure A) and press the locking plate at the opening position of the internal guide with the hand (shown as the following figure B), Fully pull out the internal guide along the direction.




Figure 2-23 Pull out internal guide

Install the internal guide to the chassis

Match the hoister hole on the internal guide with the T-type nail on the chassis side wall along the direction in the figure A and push the internal rail downward (the B direction in the figure B) till the spring locking plate on the internal rail locks one T-type nail on the chassis side wall. At this time, the internal sliding rail.




Figure 2-24 Installation method of internal rail

Install external rail to cabinet

Quick installation of support component

Shown as the following figure, adjust the external guide to proper length by sliding the rear support (A or B direction in the figure) according to the distance between front and rear pole of the cabinet and snap the locking screw of front and rear support into the corresponding hole on the front and rear upright post of the cabinet.




Figure 2-25 Install external guide to cabinet upright post

Note:

(1) The extensible scope of the external guide is 660~900mm. A user should confirm the installation size of the cabinet prior to installation.

This external rail is suitable for the cabinet with 8.8x8.8~9.5x9.5(mm) square hole of the upright post. The gap between three square holes for fixing the guide on one upright post is 15.9mm.

(2) The upright post of the cabinet should comply with the standard in the following figure.




Figure 2-26 Upright post position diagram

(3) The left and right external guide should be fixed to same scale of the left and right upright post

of the cabinet.

Up rack of chassis

The chassis enters the external rail component

Lock the machine installed with the internal guide and chassis handle into the front A of the external rail, then push inward along the direction B till the locking plate C is locked.

【Notice】 : When the internal guide is locked into the external rail and is pushed, the internal rail is locked into the rolling rail.




Figure 2-27 Install machine onto external rail

Lock support component

Respectively fix the front and rear support of left and right external guide and front and rear upright post of the cabinet (shown as the following figure), then push the rolling rail on internal and external side to the front end in A direction till it can not be pushed.




Figure 2-28 Lock external guide

Unlock push process

When the internal guide is locked, press the internal guide latch on both sides inward for unlocking (mark A in the following figure), then push the chassis inward along the direction B till the locking plate C at the sliding rail closing position is locked and the chassis can not be pushed out.




Figure 2-29 Install the chassis in place and lock it

Unlock sliding rail

To toggle the locking plate A of the sliding rail along B direction with the forefinger and unlock the internal rail and external rail, the chassis can be pushed out.

Other unlocking steps are reverse to the installation steps of the sliding rail.




Figure 2-30 Unlock chassis

3 Product configuration

3.1 LCD module

3.1.1 Typical application

The LCD display module is a new server monitoring display product, which is presented by Sugon, can display the server state information and alarms, can monitor the system operation states such as power on state, fan rotating speed, CPU temperature, BMC IP address and power consumption of Sugon Server under all weather, and provide humanistic user experiences to customers.

3.1.2 Function description

The LCD display module includes SMBus bus, interconnects the device mode and mainboard SMBus interface of the server, communicates with BMC, gets the mainboard operation information in real time, and drives the LCD to display the server operation state and information by building in the MCU into the LCD display module.

The layout of the CLD display module is shown as the figure 3-1.




Figure 3-1 LCD display module layout diagram

Table 3-1 Interface description

SN	Name	Function description
1	LCD	It is used to display server state
2	ENTER key	Enter/exit menu and view state information
3	Page key	One-way cycle menu for paging

Specific function description of LCD display module

- The background light is controlled. When the key does not respond after over 7s, the LCD module will automatically enter the dormancy mode (The LCD white background light is on for 2s and then off for 4s).
- The LCD display module interconnects the device and server BMC for communication, can monitor the server operation state in real time, and gives out alarms via the white and red background light in an alternate manner for the SYS ERR such as VOLTAGEWARNING, FAN ERR, CPU ERR and RAM ERR. A user can inquire the system information via the combined key.

3.1.3 Inquiry and operation of system-related information

Interface menu of LCD display module

The LCD display module interface of the I620-G15 chassis includes the initialization interface and L2 menu. The LCD display module can display in single line. Each line can display at most 18 characters. The system menu information can be inquired by combining the OK key and Page key.

The menu contents are shown as the figure 3-2.




Figure 3-2 LCD principle flow chart

Note: If the server system has an error (ERR information) on any menu, the LCD module will alternately flicker via the red and white light for alarm. If no ERR is available and no key is pressed within 7 min, the white background light will flicker once every 6 s. When no key is pressed, the system will restore to the initial interface after 24 hours.

Default initial interface






Figure 3-3 Initial interface

The initial display interface displays SUGON SERVER plus 2-digit code of Port80 in case of start. SUGON SERVER is fixed. 2-digit Port80 code displays when SMBus data communication changes.

Note: The Port80 will be refreshed once every 1s. On the initialization interface, to press any key, you can enter the L2 menu FAN STATUS.

Inquiry of fan status

- Under the initial status, to press any key, FAN STATUS menu will display. To press OK key under this menu, FAN STATUS L2 sub-menu will display. Otherwise, to press key  under FAN STATUS L1 menu, the CPU TEMP STATUS menu will display.
- To enter FAN STATUS L2 sub-menu, you can inquire the status of different fans of the server. The fan status will display the fan rotating speed information of the server in the format xx%. The LCD module will display FAN1 xx% (xx% is the percent of the fan rotating speed. The range is 0-100%. The following description indicates this meaning), shown as the figure 3-4.

To press key  in turn, FANi xx% will display in cycle (i=1, 2, ..., number of fans supported by the mainboard). To press the key  menu on any phase of L2 sub-menu, you can return to FAN STATUS L1 menu.









Figure 3-4 Display mode of fan status

Inquiry of CPU temperature

- To continuously press key  twice under initial status, the CPU TEMP STATUS menu will display. To press key , the CPU TEMP STATUS L2 sub-menu will display. Otherwise, to press key  under CPU TEMP STATUS L1 menu, BMC IP ADDRESS menu will display.
- To enter CPU TEMP STATUS L2 sub-menu, LCD module displays CPU1 xx°C (xx is CPU temperature. The following description indicates this meaning), shown as the figure 3-5. To press key  in turn, the CPU m xx°C will display in cycle (m=1, 2, ..., number of CPU supported by the mainboard). You should press key  on any phase of L2 sub-menu.









Figure 3-5 Display mode of CPU temperature status

BMC IP information inquiry

- Under the initial status, to continuously press key  three times, BMC IP ADDRESS menu will display. To press key , BMC IP ADDRESS L2 sub-menu will display. Otherwise, to

press key  under BMC IP ADDRESS L1 menu, the SYSTEM STATUS menu will display.

- To enter the BMC IP ADDRESS L2 menu, the LCD module displays BMC IP1 : xxx.xxx.xxx.xxx (xxx.xxx.xxx.xxx indicates the specific IP address), shown as the figure 3-6.

To press key  in turn, IPn: xxx.xxx.xxx.xxx(n=1, 2) can display in cycle. To press key  on any phase of L2 sub-menu, you can return to BMC IP ADDRESS L1 menu.







Figure 3-6 BMC IP address format

System status inquiry

- Under the initial status, to continuously press key , SYSTEM STATUS menu will display.

To press key , SYSTEM STATUS L2 sub-menu will display. Otherwise, to press key  in SYSTEM STATUS L1 menu, the POWER xxxW menu will display.

- To enter SYSTEM STATUS L2 sub-menu, if the system is under POWER ON status, the LCD module will display RUNNING... xx(xx indicates Port80 information), shown as the figure 3-7.

Otherwise, LCD module displays POWER OFF. To press key , the system will return to SYSTEM STATUS L1 menu.







Figure 3-7 System status






System power consumption inquiry

- Under the initial status, to continuously press key  five time, the POWER xxxW menu will display. The POWER xxxW menu does not include L2 sub-menu. If the system does not fail, to press page key  in POWER xxxW menu, the system will return to the initial page. If the

system fails, to press key  in POWER xxxW menu, the ERR INFORMATION menu will display.

- The system power supply power information will display under POWER xxxW m menu. The system power consumption of the whole device will display with W as the unit. The system can read the data on the display screen to view the system power consumption.

System failure information inquiry

- If the server system fails (ERR information displays) under any menu, the LCD module will flicker alternatively under the red and white background light for alarm. In addition, the system will automatically add ERROR INFORMATION menu to the L1 menu column. Under the initial status, to continuously press the key  6 times, the ERROR INFORMATION menu will display. To press  key, ERROR INFORMATION L2 sub-menu will display. Otherwise, to press key  under ERROR INFORMATION L1 menu, the system will return to the initial interface.
- To enter ERR INFORMATION L2 sub-menu, the LCD module will display SYS ERR. To press key  in turn, the LCD will display ERR information in cycle. To press key  on any phase of L2 sub-menu, the system will return to ERR INFORMATION L1 menu.

The specific failure information will display, shown as the table 3-2.



Table 3-2 Failure information report

Alarm information	Information description
SYS ERR	System error
VOLTAGE ERR	Voltage error
FAN ERR	Fan error
CPU ERR	CPU error
RAM ERR	Memory error

3.2 Eliminate CMOS jumper setting

The J3 jumper can be used to eliminate the CMOS setting on the mainboard. You can clear CMOS according to the following table:

Table 3-3 CMOS jumper clearing description

 <p>Normal (Default)</p>	The jumper will be under this position by default. At this time, the system will normally work.
 <p>Clear CMOS</p>	When CMOS will be cleared, the jumper will be cleared as this step. The jumper will set the jumper by default after 3-5s.
<p>【Notice】 Before the J3 jumper is short circuit and CMOS is cleared, make sure to fully shut down the system and plug off the AC power cable and onboard battery.</p>	

3.3 BIOS setup

- BIOS setup indicates to adjust the system and hardware parameters by using the special setup program. Setup of different parameters may lead to hardware resource confliction or reduce the system operation performance. This section will introduce the BIOS setup program. You can set the basic BIOS configurations. These settings will be stored into a memory body (called as NVRAM) and these settings will not be lost after the power turns off. It is important to know BIOS setting. You are recommended to use the default factory settings of the system.
- Before the server BIOS setting is changed, the system will record the corresponding initial setting. When the system works abnormally due to setting change, the system can resume according to the recorded initial setting.
- Generally the default system factory setting is optimal. Before the meaning of the parameters is not understood, you should not try to change it.
- This chapter will give the detailed description of the frequent settings. The seldom used options are only simply described or are not described.

Note: Sugon will reserve the right to change the system BIOS version without prior notification.

The BIOS setting method in this manual is based on the BIOS version when this manual is made, so it may make the actual interface be different from the diagrams in this manual.

3.3.1 System BIOS setup method

When the server boots and the caption displays “Sugon” text, to press or <F2> key, the system will enter BIOS setup program. You can select sub-options via the arrow in BIOS setup program. To press Return key, you can enter the sub-menu.

Note: The gray options are unavailable. The items with “▶” mark include sub-menu.

Table 3-4 Description of control key

Key	Function
<F1>	Help
<ESC>	Exit or return to the main menu from sub-menu
<←> or <→>	Select menu
<↑> or <↓>	Move cursor up or down
<Home>or<End>	Move cursor to the top or bottom of the screen
<PgUp>or<PgDn>	Move cursor to previous page or next page
<+>or<->	Select previous or next value of current item and setup
<F2>	Cancel to previous operation
<F3>	Set default
<F4>	Save and exit
<F5>	Save and restart

<Enter>

Execute command or select sub-menu

3.3.2 Main menu

The main menu is the first interface, which you first see when entering BIOS setup program. This menu will display and change basic system information. The right window displays the key description. The text information will display above it. When an item on the left window is selected, this option will be highlighted. The right window will display the description text of this option.




Figure 3-8 Main menu interface

Table 3-5 Description of Main interface parameters

Interface parameters	Function description
Compliance	Display UEFI environment version
Project Version	Display BIOS version information
Build Date and Time	Display BIOS compiling time
Main Board ID Number	Display mainboard PCB version
ROM Type	Display model of BIOS ROM memory chip
ME Version	Display ME version information
PCH Name	Display PCH model
PCH Version	Display PCH version
IOM Socket (J13) IOM Socket (J14) IOM Socket (J15) IOM Socket (J16)	Display IOM card insertion at different positions
Total Memory	Display total capacity of system memory
System Language	Set language type of BIOS option. Currently only English is supported
System Date	Set system date
System Time	Set system time

Note: BIOS version is only for reference. For the latest version, refer to the version issued by Sugon.

3.3.3 Advanced menu

Advanced menu permits a user to change settings of the system CPU and other devices.

【Notice】 You should carefully change the menu setting. Incorrect setting may lead to system crash.




Figure 3-9 Advanced menu interface

Table 3-6 Description of Advanced interface parameters

Interface parameters	Function description
Benchmark Recommendation Setting	Recommended setting for benchmark test
ACPI Settings	Advanced configuration and power management interface setting
Wakeup Event Setup	Device wake on LAN (WOL) event configuration
Serial Port Console Redirection	Serial port redirection configuration
PCI Subsystem Settings	PCI sub-system configuration
Network Stack Configuration	Network protocol stack configuration
CSM Configuration	Compatibility module configuration
NCT6779D HW Monitor	Display temperature and voltage monitoring information of partial hardware
H/W Monitor	Display hardware detection information and set fan strategy

Benchmark Recommendation Setting




Figure 3-10 Benchmark Recommendation Setting menu interface

Table 3-7 Description of Benchmark Recommendation Setting interface parameter

Interface parameters	Function description
Benchmark Recommendation Configuration	Benchmark test preference setup




Figure 3-11 ACPI Settings interface

Table 3-8 Description of ACPI Settings interface parameters

Interface parameters	Function description
Enable ACPI Auto Configuration	Advanced configuration and automated configuration of power management interface
Enable Hibernation	Support dormancy mode
Lock Legacy Resources	Support traditional power management resource




Figure 3-12 Wakeup Event Setup interface

Table 3-9 Description of Wakeup Event Setup interface parameters

Interface parameters	Function description
Wake On LAN	Network wakeup function setup
Wake system from RTC	Clock wakeup function setup




Figure 3-13 Serial Port Console Redirection interface

Table 3-10 Description of Serial Port Console Redirection interface

Interface parameters	Function description
(COM0) Console Redirection	Enable/disable COM0 console redirection
(COM0) Console Redirection Settings	COM0 console redirection setup
(COM1) Console Redirection	Enable/disable COM1 console redirection
(COM1) Console Redirection Settings	COM1 console redirection setup. To click it, the system can enter the setup interface

(COM0) Console Redirection Settings




Figure 3-14 (COM0) Console Redirection Settings interface

Table 3-11 Description of (COM0) Console Redirection Settings

Interface parameters	Function description
Terminal type	Terminal type
Bits per second	Transmission speed (bit/s)
Data Bits	Data bit
Parity	Set if parity is available
Stop Bits	Stop bit
Flow Control	Set if traffic control is required
VT-UTFB Combo Key Support	Set if VT-UTFB combination key is supported
Recorder Mode	Enable/disable recording mode
Resolution 100x31	Set if the resolution 100x31 is supported
Legacy OS Redirection Resolution	Redirection resolution of previous system
Putty Keypad	Selection of Putty small keyboard mode
Redirection after BIOS POST	Redirection setup after BIOS starts

(EMS) Console Redirection Settings




Figure 3-15 (EMS) Console Redirection Settings configuration interface

Table 3-12 Description of (EMS) Console Redirection Settings configuration interface

Interface parameters	Function description
Out-of-Band Mgmt Port	Set out-band management port
Terminal Type	Set terminal type
Bits per second	Set transmission speed (bit/s)
Flow Control	Property of serial port with optional SOL and COM
Data Bits	Width of data bit
Parity	Set if parity check is available
Stop Bits	Stop bit

PCI Subsystem Settings




Figure 3-16 PCI Subsystem Settings configuration interface

Table 3-13 Description of PCI Subsystem Settings configuration interface

Interface parameters	Function description
Above 4G Decoding	Over 4G memory address space access switch, which supports decoding of over 4G address space of 64-bit PCI device
SR-IOV Support	PCIe device virtualization function control switch

Network Stack Configuration




Figure 3-17 Network Stack Configuration interface

Table 3-14 Description of network Stack Configuration interface

Interface parameters	Function description
Network Stack	Set if UEFI PXE is enabled to support the network protocol stack (network device UEFI Driver support required)

CSM Configuration




Figure 3-18 CSM Configuration interface

Table 3-15 Description of CSM Configuration interface

Interface parameters	Function description
CSM Support	Set if the module compatibility is supported
OpROM Selection	OpROM switch option of external plug-in PCIE device
CSM16 Module Version	Display CSM16 module version
GateA20 Active	Select to keep GateA20 on or off all the time
Option ROM Messages	Select information display mode of Option ROM
INT19 Trap Response	Capture information on interruption 19
Boot option filter	Control start priority sequence of Legacy ROM and UEFI ROM
Network	Parameter configuration of network device UEFI/Legacy PXE OpROM
Storage	Parameter configuration of storage device UEFI/Legacy OpROM
Video	Parameter configuration of display device UEFI/Legacy OpROM
Other PCI device	Parameter configuration of UEFI/Legacy OpROM parameter

NCT6679D HW Monitor

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Advanced

Pc Health Status

PSU1_Amb_Temp	: +38 °C
PSU2_Amb_Temp	: +35 °C
PCI1_Amb_Temp	: +35 °C
PCI2_Amb_Temp	: +34 °C
SYS1_Temp	: +28 °C
SYS2_Temp	: +29 °C
PCH_Temp	: +61 °C
+1.5V_SSB	: +1.504 V
+1.2VAUX_BMC	: +1.240 V
+1.5VAUX_BMC	: +1.504 V
+VTDDR_AB	: +0.584 V

++: Select Screen
 ↑↓: Select Item
 Enter: Select
 +/-: Change Opt.
 F1: General Help
 F2: Previous Values
 F3: Optimized Defaults
 F4: Save & Exit
 F5: Save & Reset
 ESC: Exit

Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.

H/W Monitor

Aptio Setup Utility - Copyright (C) 2013 American Megatrends, Inc.

Advanced

Pc Health Status

CPU0_Temp	: +33 °C
CPU1_Temp	: +38 °C
BMC_Temp	: +35 °C
SYS_FAN1	: N/A
SYS_FAN2	: N/A
SYS_FAN3	: N/A
SYS_FAN4	: N/A
SYS_FAN5	: N/A
SYS_FAN6	: N/A
SYS_FAN7	: N/A
SYS_FAN8	: N/A
CPU_FAN1	: 7584 RPM
CPU_FAN2	: 2641 RPM
+VCORE0	: +1.812 V
+VCORE1	: +1.804 V
+VCCIO	: +1.044 V
+VDDQ_AB_CPU0	: +1.216 V
+VDDQ_CD_CPU0	: +1.212 V
+VDDQ_EF_CPU1	: +1.212 V
+VDDQ_GH_CPU1	: +1.216 V
+1.05V_SSB	: +1.044 V
+1.05VSB_SSB	: +1.080 V
+12V	: +11.856 V

Fan Control Mode

++: Select Screen
 ↑↓: Select Item
 Enter: Select
 +/-: Change Opt.
 F1: General Help
 F2: Previous Values
 F3: Optimized Defaults
 F4: Save & Exit
 F5: Save & Reset
 ESC: Exit

Version 2.16.1243. Copyright (C) 2013 American Megatrends, Inc.




Figure 3-19 H/W Monitor menu interface

Table 3-16 Description of H/W Monitor interface parameter

Interface parameters	Function description
Fan Control Mode	Set fan speed adjustment mode

3.3.4 Chipset menu





Figure 3-20 Chipset menu interface

Table 3-17 Description of Chipset interface parameter

Interface parameters	Function description
RC Revision	Intel MRC version information
Processor Configuration	Processor configuration
Advanced Power Management Configuration	Advanced power management configuration
Common RefCode Configuration	Frequent reference code configuration
QPI Configuration	QPI link configuration
Memory Configuration	Memory configuration
IIO Configuration	Integrated input/output configuration
PCH Configuration	Chipset configuration
Miscellaneous Configuration	Other configurations

Processor Configuration






Figure 3-21 Processor Configuration menu interface

Table 3-18 Description of Processor Configuration interface parameters

Parameter name	Configuration description
Processor Socket	Processor socket SN
Processor ID	Processor ID
Processor Frequency	Processor frequency
Processor Max Ratio	Processor maximum frequency doubling
Processor Min Ratio	Processor minimum frequency doubling
Microcode Revision	Processor micro-code version information
L1 Cache RAM	L1 cache capacity
L2 Cache RAM	L2 cache capacity
L3 Cache RAM	L3 cache capacity
Processor 0 Version Processor 1 Version	Processor model
Execute Disable Bit	Enable/disable EDB technology. After it is enabled, it can enhance the system security and avoid virus intrusion.
Enable Intel TXT Support	Set if the trustable execution technology support is enabled or not, which is an enhanced virtual machine security technology
VMX	Enable/disable CPU virtualization technology
Enable SMX	Enabled/disable secure mode expansion technology. After it is enabled, it can enhance the data security inside the processor
MSR Lock Control	Special register locking control of CPU module
Lock Chipset	Set if the chipset register table is locked. After it is enabled, it can enhance the system security.
PPIN Control	Enable/disable processor stock number protection
DEBUG INTERFACE	Enable/disable diagnosis interface
Hardware Prefetcher	Enable/disable hardware pre-fetching function. After it is enabled, the command and data in the memory can be fetched to the buffer to improve the system performance.
DCU Streamer Prefetcher	After it is enabled, the data stream is fetched form the cache to DCU (data cache unit) to improve the data read/write and processing speed and enhance system performance
DCU IP Prefetcher	After it is enabled, the system will fetch IP address and enhance

	network performance
DCU Mode	Set DCU mode to enable L1 cache correction function
Direct Cache Access (DCA)	Enable/disable direct cache access technology. After it enabled, it can enhance data access and transmission efficiency.
DCA Prefetch Delay	Set DCA fetching delay
X2APIC	Extended advanced programmable interruption controller
AES-NI	Enable/disable new command technology of advanced encryption standard. After it is enabled, it can enhance data security.

Advanced Power Management Configuration




Figure 3-22 Advanced Power Management Configuration menu interface

Table 3-19 Description of Advanced Power Management Configuration interface parameters

Parameter name	Configuration description
Power Technology	The power management strategy selection (energy efficient: it is used to support power energy saving mode; Custom: it is used to set the self-defined system power; Disable: it is used to forbid power energy saving setup. Option: Disable, Energy Efficient (default) or Custom).
Config TDP	Configure designed power consumption of heat dissipation
CPU P State Control	Processor power status parameter setup
CPU C State Control	Processor idle status parameter setup

CPU P State Control




Figure 3-23 CPU P State Control menu interface

Table 3-20 description of CPU P State Control interface parameter

Parameter name	Configuration description
EIST (P-State)	Enable/disable Intel intelligent under-locking technology
Turbo Mode	Core operation dynamic acceleration mode
P-State coordination	Set power status supported by processor

CPU C State Control




Figure 3-24 CPU C State Control menu interface

Table 3-21 Description of CPU C State Control interface parameter

Parameter name	Configuration description
C2C3TT	Set transition time from C2 status to C3 status
Package C State Limit	Processor idle status limit configuration
CPU C3 Report	Enable/disable BIOS to report C3 idle status to OS
CPU C6 Report	Enable/disable BIOS to report C6 idle status to OS
Enhanced Halt State (C1E)	Enable/disable enhanced idle power management status switching. After it is enabled, it can reduce CPU voltage and frequency under idle CPU status and save power.

Common RefCode Configuration




Figure 3-25 Common RefCode Configuration menu interface

Table 3-22 Description of Common RefCode Configuration interface parameter

Parameter name	Configuration description
NUMA	Enable/disable inconsistent memory access technology

QPI Configuration




Figure 3-26 QPI Configuration menu interface

Table 3-23 Description of QPI Configuration interface parameter

Parameter name	Configuration description
QPI General Configuration	QPI general setting

QPI General Configuration




Figure 3-27 QPI General Configuration menu interface

Table 3-24 Description of QPI General Configuration interface parameter

Parameter name	Configuration description
QPI Status	Display QPI status
COD Enable	Cluster on Die mode is used to reduce communication between two CPU partitions and improve performance
Early Snoop	Early probe

QPI Status




Figure 3-28 QPI Status menu interface

Memory Configuration




Figure 3-29 Memory Configuration menu interface

Table 3-25 Description of Memory Configuration interface parameter

Interface parameters	Function description
Memory Frequency	Memory frequency setup
ECC Support	ECC function support setup
Memory Topology	Display information on installed memory
Memory Map	Memory mapping setting
Memory RAS Configuration	Memory RAS feature setting

Memory Topology



Memory Map




Figure 3-30 Memory Map menu interface

Table 3-26 Description of Memory Map interface parameter

Interface parameters	Function description
Channel Interleaving	Set crossing mode of memory channel level
Rank Interleaving	Set crossing mode of memory Rank level

Memory RAS Configuration




Figure 3-31 Memory RAS Configuration menu interface

Table 3-27 Description of memory RAS Configuration interface parameter

Interface parameters	Function description
RAS Mode	Set RAS mode
Lockstep x4 DIMMs	Enable/disable step mode x4 DiMM
Memory Rank Sparing	Set if the memory Rank redundancy function is enabled

IIO Configuration




Figure 3-32 I/O Configuration menu interface

Table 3-28 Description of I/O Configuration interface parameter

Interface parameters	Function description
IOAT Configuration	Integrated input/output acceleration configuration
Intel VT for Directed I/O (VT-d)	Virtualization technology setting of Intel direct IO access

IOAT Configuration




Figure 3-33 IOAT Configuration menu interface

Table 3-29 Description of IOAT Configuration interface parameter

Interface parameters	Function description
Enable IOAT	Enable/disable Intel input/output acceleration technology
No Snoop	Enable/disable PCI-E non-monitoring function
Disable TPH	Enable/disable TLP processing prompt
Relaxed Ordering	Relax sorting

Intel VT for Directed I/O (VT-d)




Figure 3-34 Intel VT for Directed I/O (VT-d) menu interface

Table 3-30 Description of Intel VT for Directed I/O (VT-d) interface parameter

Interface parameters	Function description
VTd Azalea VcP Optimization	Intel IO virtualization configuration option
Intel VT for Directed I/O (VT-d)	Enable/disable Intel hardware assisted virtualization function. To enable this function, the system can bear more work load, improve reliable and reduce TCO.
Interrupt Remapping	Enable/disable interruption re-mapping function
Coherency Support (non-Isch)	Enable/disable (non-synchronization mode) consistency support
Coherency Support (Isch)	Enable/disable (synchronization mode) consistency support

PCH Configuration




Figure 3-35 PCH Configuration menu interface

Table 3-31 Description of PCH Configuration interface parameter

Interface parameters	Function description
PCH Devices	PCH device configuration
PCH sSATA Configuration	PCH sSATA configuration
PCH SATA Configuration	PCH SATA configuration
USB Configuration	USB configuration

PCH Devices




Figure 3-36 PCH Devices menu interface

Table 3-32 Description of PCH Devices interface parameter

Interface parameters	Function description
Restore AC Power Loss	This function is used to set the power operation status when the system power is disconnected and powers on again. To select Stay off, it indicates that the system power will keep power off status after power interruption and power on. To select power on, it indicates that the system power will automatically power on after power interruption and power on again. To select Last state, it indicates that the system power will restart the final power status after interruption and power on.
Power Button Function	Set machine power button. If it is set as emergency off button, when a user presses the power button, the system will instantly power off. If it is set as 4 Seconds Override, when the user holds the power button for 4s or longer, the system will power off.

PCH sSATA Configuration




Figure 3-37 PCH sSATA Configuration menu interface

Table 3-33 Description of PCH sSATA Configuration interface parameter

Interface parameters	Function description
sSATA Controller	Enable/disable sSATA controller
Configure sSATA as	Configure sSATA mode, which can be set as IDE, AHCI or Raid mode
sSATA Port 0 sSATA Port 1 sSATA Port 2 sSATA Port 3	Display hard disk information at sSATA interface. When the hard disk is not connected, "Not Installed" will display. To connect the hard disk, the detailed hard disk information will display.

PCH SATA Configuration




Figure 3-38 PCH SATA Configuration menu interface

Table 3-34 Description of PCH SATA Configuration interface parameter

Interface parameters	Function description
SATA Controller	Enable/disable SATA controller
Configure SATA as	Configure SATA mode, which can be set as IDE, AHCI or Raid mode
SATA Port 0 SATA Port 1 SATA Port 2 SATA Port 3	Display hard disk information at SATA interface. When the hard disk is not connected, "Not Installed" will display. To connect the hard disk, the detailed hard disk information will display.

USB Configuration




Figure 3-39 USB Configuration menu interface

Table 3-35 Description of USB Configuration interface parameter

Interface parameters	Function description
xHCI Mode	Scalable host controller interface mode setup (down compatible to USB3.0)
USB Ports Per-Port Disable Control	Set if each USB interface is disabled
Rear USB Port #0 control	Control switch of USB interface 0 on the rear of the chassis
Rear USB Port #1 control	Control switch of USB interface 1 on the rear of the chassis
Front USB Port #0 control	Control switch of USB interface 0 on the front panel of the chassis
Front USB Port #1 control	Control switch of USB interface 1 on the front panel of the chassis
Vertical USB Port #0 Control	Vertical USB interface control switch on mainboard

3.3.5 Server Mgmt menu

The Server Mgmt menu can set BMC options.




Figure 3-40 Server Mgmt menu interface

Table 3-36 Description of Server Mgmt interface parameter

Interface parameters	Function description
BMC Self-Test Status	BMC self-test status
BMC Device ID	BMC device ID number
BMC Device Revision	BMC device revision
BMC Firmware Revision	BMC firmware revision
IPMI Version	Supported IPMI standard version
BMC Support	Enable/disable BMC function
FRB-2 Timer	Failure recovery and start in Post
FRB-2 Timer timeout	Failure recovery and start time setup in Post
FRB-2 Timer Policy	Failure recovery and start handling mechanism in Post
OS Watchdog Timer	Watchdog timeout setting in OS
OS Wtd Timer Timeout	Watchdog timeout duration setting in OS
OS Wtd Timer Policy	Watchdog timeout handling mechanism in OS
Serial Mux	Serial communication
System Event Log	System event log setting
BMC Self test log	BMC self-test log setting
View FRU information	View FRU information
BMC network configuration	BMC network setting
View System Event Log	View system event log
BMC User Settings	BMC user setting, including addition, deletion and change of BMC user information
BMC Warm Reset	BMC warm reset. To select it and press Enter key, the system will prompt if the BMC boots in a warm manner. To select Yes, the BMC will boot in a warm manner.

System Event Log




Figure 3-41 System Event Log menu interface

Table 3-37 Description of system Event Log interface parameter

Interface parameters	Function description
SEL Components	Enable/disable system log configuration function. To enable this function, the system log operation function can be bonded
Erase SEL	Set if the system log is cleared in case of restart
When SEL is Full	Set actions when the stored system logs are full
Log EFI Status Code	Record status code setup of EFI

BMC self-test log





Figure 3-42 BMC self test log menu interface

Table 3-38 Description of BMC self-test log interface parameter

Interface parameters	Function description
Erase Log	Set if the BMC self-test log is cleared in case of restart
When log is full	Set actions when the log is stored fully

[View FRU information](#)






Figure 3-43 BMC Network Configuration menu interface

Table 3-39 Description of BMC Network Configuration interface parameter

Interface parameters	Function description
BMC LAN Mode	Network management mode: according to the different system, it offers different option as below : Unspecifie Dedicate: only use dedicate Ethernet port Share 1G: only use share 1G Ethernet port Share 10G:only use share 10G Ethernet port Failover 1G : use the dedicate Ethernet port and share 1G Ethernet port at the same time by supporting Failover function. Failover 10G : use the dedicate Ethernet port and share 10G Ethernet port at the same time by supporting Failover function.
Current BMC LAN Mode	
Configuration Address source	Configure the source of IP address
Current Configuration Address sour	Display current IP address source
Station IP address	Display current IP address
Subnet mask	Display current subnet mask
Station MAC address	Display MAC address of network interface
Router IP address	Display IP address of router by default
Router MAC address	Display MAC address of router by default
Save Configuration	Save setting

View System Event Log




Figure 3-44 View System Event Log menu interface

BMC User Settings



Figure 3-45 BMC User Settings menu interface

Table 3-40 Description of BMC User Settings interface parameter

Interface parameters	Function description
----------------------	----------------------

Add User	Add BMC user
Delete User	Delete BMC user
Change User Settings	Change BMC user setting

Add User




Figure 3-46 Add User menu interface

Table 3-41 Description of BMC User Settings interface parameter

Interface parameters	Function description
User Name	Input BMC user name, which should not be same as the existing user name
User Password	Input BMC user password, which should be inputted two times and should be fully same.
Channel No	Set channel number
User Privilege Limit	Set user privilege

Delete User




Figure 3-47 Delete Users menu interface

Table 3-42 Description of Delete User interface parameter

Interface parameters	Function description
User Name	Input the user name to delete, which should exist
User Password	Input user password. If it is correct, this user will be deleted.

Change User Setting




Figure 3-48 Change User Settings menu interface

Table 3-43 Description of Change User Settings interface parameter

Interface parameters	Function description
User Name	Input user name to change
User Password	Input user password to change
User	Set if this user is enabled
Change User Password	Change user password, which should be inputted two times and should be fully same
Channel No	Change user channel number
User Privilege	Change user privilege

3.3.6 Security menu




Figure 3-49 Security menu interface

Table 3-44 Description of security interface parameter

Interface parameters	Function description
Administrator Password	Add/change/delete user password of administrator privilege
User Password	Add/change/delete user password of general user privilege
【Notice】 The minimal length of the password is 3 characters. The maximum length is 20 characters.	

3.3.7 Boot menu

This menu can configure the start device.




Figure 3-50 Boot menu interface

Table 3-45 Description of Boot interface parameter

Interface parameters	Function description
Setup Prompt Timeout	Set time for waiting for Setup key (the unit is s)
Bootup NumLock State	Set status of NumLock key in case of power on
Quiet Boot	Enable/disable POST OEM logon display function. When this function is enabled, OEM logo will display. When this function is disabled, the self-test information will display
UEFI Boot	Enable/disable UEFI start option. If Auto is selected, when the first start hard disk uses GTP partition format, UEFI start mode is enabled.
Boot Option Priorities	Set priority sequence of start items
Network Device BBS Priorities	Set priority sequence of network start equipment
CD/DVD ROM BBS Priorities	Set priority sequence of CD ROM start device
Hard Drive BBS Priorities	Set priority sequence of hard disk start device
Floppy Drive BBS Priorities	Set priority sequence of floppy disk start device
Delete Boot Option	Delete start items

3.3.8 Save & Exit menu




Figure 3-51 Save & Exit menu interface

Table 3-46 Description of Save & Exit interface parameter

Interface parameters	Function description
Save Changes and Exit	Save setting and exit
Discard Changes and Exit	Discard change and exit
Save Changes and Reset	Save setting and restart
Discard Changes and Reset	Discard change and restart
Save Changes	Save setting
Discard Changes	Discard change
Restore Defaults	Restore default
Save As User Defaults	Save as default user value
Restore User Defaults	Restore default user value
Boot Override	Boot override. To select the following booting items, you can directly boot from this start item, but it will change set booting sequence.

3.4 BMC configuration

To open IE browser and input server IP address at the URL column, you can enter the server system management platform, shown as the figure 3-52.

Username:
Password:
[Forgot Password?](#)

Required Browser Settings

1. Allow popups from this site ✓
2. Allow file download from this site. (How to ?)
3. Enable javascript for this site ✓
4. Enable cookies for this site ✓

It is recommended not to use Refresh, Back and Forward options of the browser.

Figure 3-52 login interface

After the user enters the system management platform, he should input admin at the username and password field and click login, then he can enter the main interface, shown as the figure 3-53.




Figure 3-53 User entry interface

The whole management platform includes several parts in the figure 3-54.




Figure 3-54 Management platform items

Table 3-47 Description of management platform

Option	Description
Dashboard	Information view, which gives all status information of the device and remote server
FRU&DMI	View FRU information and DMI information, including basic system information, frequent header information, chassis information, mainboard information and FRU component information.
Server Health	Server operation condition, which displays the data on server

	operation status, including sensor reading and event record.
Component Information	Component information, which displays CPU, memory, hard disk, PCI device, power and network card information
Configuration	Configuration, which can configure the device such as DNS, LDAP, NTP and PEF.
Remote Control	Remote control, which permits the user to remotely operate the server, including remote console start and server power control
Auto Video Recording	Automated video recording, which can configure the trigger conditions of automated video recording and view and handle recorded videos.
Maintenance	Maintenance, which can restore factory setting of the device configuration and reserve partial setting
Firmware Update	Firmware upgrade, which can remotely refresh the BIOS and BMC on Web interface

3.4.1 Dashboard

To click Dashboard menu, the interface is shown as the figure 3-53. The interface includes the following modules:

Device information module

Device Information

Firmware Revision: 0.07.5
 Firmware Build Time: Oct 17 2014 14:44:05 CST
 System GUID: 00000001-9DBC-4022-4496-1F4050CCA443

Figure 3-55 Device information module

The figure 3-55 shows the basic device information, displaying firmware version, firmware compiling time and system GUID from up to down.

Note: the firmware version is only for reference. For the latest version, refer to the version issued by Sugon.

Network information module

Network Information [\(Edit\)](#)

Dedicate LAN: Enable
 MAC Address: 78:24:AF:02:1F:EE
 V4 Network Mode: DHCP
 IPv4 Address: 10.0.21.25
 V6 Network Mode: DHCP
 IPv6 Address: ::
 Share LAN: Enable
 MAC Address: 00:1F:C6:00:00:02
 V4 Network Mode: DHCP
 IPv4 Address: 0.0.0.0
 V6 Network Mode: DHCP
 IPv6 Address: ::

Figure 3-56 Network information module

The figure 3-56 displays the network management information and two management network interfaces and Dedicated LAN and Share LAN. The figure displays the status information of two network interfaces. To click “Edit”, the system will switch to network setting interface under Configuration menu.

It will be introduced in details in the late part.

Remote console module







Figure 3-57 Remote console module

The figure 3-57 displays the remote console module. To click Launch button, the remote console will start. The black area in the figure under the power status will display the screen snapshot. To click “Refresh” button, the snapshot will be refreshed.

Sensor information module

Sensor Monitoring			
Status	Sensor	Reading	
●	CPU0_Temp	47 ° C	🔍
●	CPU1_Temp	41 ° C	🔍
●	LAN_Temp	38 ° C	🔍
●	PCH_Area_Temp	41 ° C	🔍
●	MB_Inlet_Temp	27 ° C	🔍
●	CPU0 VCore	0.83 Volts	🔍
●	CPU1 VCore	0.87 Volts	🔍
●	CPU0 Memory	1.56 Volts	🔍
●	CPU1 Memory	1.55 Volts	🔍
●	3.3V	3.384 Volts	🔍
●	5V	5.103 Volts	🔍
●	12V	12.22 Volts	🔍
●	VBATV	3.306 Volts	🔍
●	SYS_FAN_1	Not Available	🔍
●	SYS_FAN_2	11200 RPM	🔍
●	SYS_FAN_3	10160 RPM	🔍

Figure 3-58 Sensor information module (part)

The figure 3-58 displays monitoring information of some sensors. This module includes sensor status, name and reading. The icon  indicates to exceed the critical value and is under the alarm status. The icon  indicates normal status. To click the icon , the system will switch to sensor readings interface under Server Health. It will be introduced in the late part in details.

Event log module





Figure 3-59 Event log module

The figure 3-59 displays the log statistics information. To click the color box before logs (e.g. ) , you will enter the detailed information interface. The percent in the bracket after the event item will indicate the percent of this item in the total logs. The left side shows the pie chart.

3.4.2 FRU & DMI

To click FRU&DMI, the following interface will display.




Figure 3-60 FRU&DMI sub-menu

FRU Information

To select FRU Information item, the interface is shown as the figure 3-61.




Figure 3-61 FRU information interface

Table 3-48 Description of basic information

Information item	Description
FRU Device ID	FRU device ID
FRU Device Name	FRU device name

Table 3-49 Chassis Information

Information item	Description
Chassis Type	Chassis type
Chassis Part Number	Number of Chassis part
Chassis Serial Number	Chassis SN

Table 3-50 Description of Board Information

Information item	Description
Board Manufacturer	Mainboard manufacturer
Board Product Name	Name of mainboard product
Board Serial Number	Mainboard SN
Board Part Number	Number of mainboard part

Table 3-51 Description of Product Information

Information item	Description
Manufacturer Name	Manufacturer name
Product Name	Product part number
Product Part Number	Number of product part

Product Version	Product version
Product Serial Number	Product SN
Asset Tag	Asset tag

DMI Information

To select DMI Information, the interface is shown as the figure 3-62.




Figure 3-62 DMI information interface

Table 3-52 Description of BIOS Information

Information item	Description
BIOS Version	BIOS version
BIOS Build Date	BIOS building time

Table 3-53 Description of System Information

Information item	Description
System Vender	System manufacturer
System Module Name	Name of system model
System Version	System version
System Serial Number	System SN

Table 3-54 Description of Board Information

Information item	Description
Board Vender	Mainboard manufacturer
Board Name	Mainboard model
Board Version	Mainboard version
Board Serial Number	Mainboard SN

3.4.3 Server Health

To click Server Health menu, the sub-menu is shown as the figure 3-63.




Figure 3-63 Server Health sub-menu

Sensor Readings

To select Sensor readings, the interface is shown as the figure 3-64. This interface includes information on all sensors. The drag-down menu at the left top corner can be used to select the sensor by category. The options include All Sensors, Temperature Sensors, Voltage Sensors, Fan Sensors, Physical Security, Processor, Power Supply, Memory, System ACPI Power Status and Watchdog 2.




Figure 3-64 Sensor reading main interface

The interface on the figure 3-64 is divided into three areas, which are introduced as follows:

Sensor list area:

All Sensors ▾

Sensor Name ▾	Status ▾	Current Reading ▾
CPU0_DIMMA0_Temp	Normal	35 ° C
CPU0_DIMMA1_Temp	Not Available	Not Available
CPU0_DIMMA2_Temp	Not Available	Not Available
CPU0_DIMMB0_Temp	Normal	37 ° C
CPU0_DIMMB1_Temp	Not Available	Not Available
CPU0_DIMMB2_Temp	Not Available	Not Available
CPU0_DIMMC0_Temp	Not Available	Not Available
CPU0_DIMMC1_Temp	Not Available	Not Available
CPU0_DIMMC2_Temp	Not Available	Not Available
CPU0_DIMMD0_Temp	Not Available	Not Available
CPU0_DIMMD1_Temp	Not Available	Not Available
CPU0_DIMMD2_Temp	Not Available	Not Available
NM Capabilities	Supported	Supported
CPU1_DIMME0_Temp	Normal	34 ° C
CPU1_DIMME1_Temp	Not Available	Not Available
CPU1_DIMME2_Temp	Not Available	Not Available
CPU1_DIMMF0_Temp	Normal	33 ° C
CPU1_DIMMF1_Temp	Not Available	Not Available
CPU1_DIMMF2_Temp	Not Available	Not Available
CPU1_DIMMG0_Temp	Not Available	Not Available

Figure 3-65 Sensor list area (part)

The figure 3-65 shows the sensor list. This list includes all sensors and gives the sensor name, status and current readings.

Detailed information on sensor:

CPU0_DIMMC1_Temp: Not Available **NOT AVAILABLE**

Thresholds for this sensor Live Widget N/A |

Lower Non-Recoverable (LNR):	0 ° C	Upper Non-Recoverable (UNR):	85 ° C
Lower Critical (LC):	3 ° C	Upper Critical (UC):	83 ° C
Lower Non-Critical (LNC):	5 ° C	Upper Non-Critical (UNC):	81 ° C

[Threshold Settings](#)

Figure 3-66 Detailed sensor information area

This figure displays the detailed information area of the sensor and detailed information on the selected sensor, including sensor name, reading, status and threshold. For the meaning of the threshold, refer to the table 3-55.

Table 3-55 Description of temperature sensor threshold

Information item	Description
Lower Non-Recoverable (LNR)	Low non-recoverable value
Lower Critical (LC)	Low critical value
Lower Non-Critical (LNC)	Low non-critical value
Upper Non-Recoverable (UNR)	High non-recoverable value
Upper Critical (UC)	High critical value

Upper Non-Critical (UNC)	High non-critical value
--------------------------	-------------------------

To click “Threshold Settings” button, the threshold setup interface will pop up, shown as the figure3-67. The thresholds of the selected sensors can be set.




Figure 3-67 Threshold setup interface

Sensor event statistics diagram

Graphical View of this sensor's events




Figure 3-68 Sensor event statistics diagram

The figure 3-68 shows the selected sensor event statistics diagram. The vertical axis displays the event level and the horizontal axis displays the event number. To click “View this Event Log” button, you can enter the event log list of this sensor of this event log.

Event Log

To select Event Log under Server Health menu, the figure 3-69 will displays.




Figure 3-69 Time log interface

The figure shows the event log interface. The list displays all event logs on the figure. Two drag-down boxes at the left up corner will filter the logs. The left drag-down box can filter the log according to the log source, including System Event Records, OEM Event Records, BIOS Generated Events, SMI Handler Events, System Management Software Events, System Software-OEM Events, Remote Console Software Events and Terminal Mode Remote Console Software Events. The right drag-down box can filter the event logs according to the sensor.

To click “Save Event Log” button, the log can be saved locally.

To click “Clear All Event Logs”, all logs can be deleted.

【Notice】 This step can be operated carefully!

System and Audit Log

To select System and Audit Log under Server Health, the interface is shown as the figure 3-70.




Figure 3-70 System Log interface

The interface includes System Log and Audit Log label tab, which are introduced as follows:

System Log: The interface is shown as the figure, which records the system generated log. The

drag-down box at the left up corner can show logs at different levels, including Alert, Critical, Error, Notification, Warning, Debug, Emergency and Information level.

Audit Log: The interface is shown as the figure, which records some action log of the user, e.g. login, logout, remote power on/off and log saving.




Figure 3-71 Audit Log interface

BSOD Screen

To BSOD Screen item under Server Health menu, the interface is shown as the figure 3-72.




Figure 3-72 BSOD Screen interface

This interface will snapshot the blue screen in case of system crash and display it.

3.4.4 Component Information

To click Component Information menu, the interface is shown as the figure.




Figure 3-73 CPU information display

The figure shows 9 label tabs on the interface, including CPU, Memory, Onboard Hard Disk, Hard Disk, PCIe Device, PSU, FAN Onboard NIC, and Expander NIC, which are introduced as follows:

CPU :

The interface is shown as the figure 3-74. The monitoring information is shown as the following table.

Table 3-56 Description of CPU information

Information items	Description
Number	Item number
Location	Position
Present	Post status
Information	Model information

Memory :




Figure 3-74 Memory information interface

Table 3-57 Description of Memory information

Information items	Description
Number	Item number
Location	Position
Present	Post status
Type	Memory type
Frequency	Memory frequency
Size	Memory capacity
Manufacture	Manufacturer
Part Number	SN
ECC Count	ECC error number
UnECCC State	Non-recoverable ECC error status
MRC State	MRC status

Onboard Hard Disk :




Figure 3-75 Onboard Hard Disk information interface

Table 3-58 Description of Onboard Hard Disk information

Information items	Description
Number	Item number
Location	Position
Mode	Mode
Serial No.	SN
FW Version	Firmware version
Model Name	Model name
Size	Hard disk capacity

Hard Disk :




Figure 3-76 Hard Disk information interface

Table 3-59 Description of Hard Disk information

Information items	Description
Number	Item number
Location	Position
Present	Post status
State	Status
Run State	Operation status

PCIe Device :




Figure 3-77 PCIe Device information interface

Table 3-60 Description of PCIe Device information

Information items	Description
Number	Item number
Location	Position
Present	Post status
Manufacture	Manufacturer
Class	Classification
State	Status

PSU :




Figure 3-78 PSU information interface

Table 3-61 Description of PSU information

Information items	Description
Number	Item number
Location	Position
Present	Post status
Power In	Input power
Vout	Output voltage
Fan	Rotating speed of power fan
Temp	Power temperature
StateCode	Status code
Total Power	Total system power

FAN:




Figure 3-79 FAN information interface

Table 3-62 Description of FAN information

Information items	Description
Number	Item number
Location	Position
Present	Post status
Fan Speed	Fan speed of system

State	Fan status of system
-------	----------------------

Onboard NIC :




Figure 3-80 Onboard NIC information interface

Table 3-63 Description of Onboard NIC information

Information items	Description
Number	Item number
Location	Position
Link State	Link status
Link Speed	Link speed
Vender	Manufacturer
MAC Address	MAC address
State	Status

Expander NIC :




Figure 3-81 Expander NIC information interface

Table 3-64 Description of Expander NIC information

Information items	Description
Number	Item number

Location	Position
Port	Port
Vender	Manufacturer
MAC Address	MAC address

3.4.5 Configuration

To click Configuration menu, the menu displays as the figure 3-82.



Figure 3-82 Configuration sub-menu

The sub-menus are introduced as follows:

Active Directory

To select Active Directory, a user can enter the active directory setup interface, shown as the figure 3-83.




Figure 3-83 Active directory interface

To click the button **Advanced Settings** at the right up corner, a user can set the advanced options and the figure 3-84 interface displays.

Figure 3-84 Advanced active directory setup interface

Table 3-65 Description of BIOS Information

Information items	Description
Active Directory Authentication	Check the checkbox before Enable and enable this function
Secret Username	Private user name
Secret Password	Private user password
User Domain Name	To set a domain name, The BMC device will be added to this domain.
Domain Controller Server Address1 Domain Controller Server Address1 Domain Controller Server Address1	Set the address of the domain control server and at least set one address.

After setting is completed, to click the button **Save**, you can save the setting and then set Role Group. Each Role Group setting item can be used to set the BMC access privilege of a user in the group. At least 5 items can be sets. To select the blank item and click the button

Add Role Group; the setup box for adding role group is shown as the figure 3-85.

Figure 3-85 Role group addition interface

Table 3-66 Description of role group addition interface

Information items	Description
Role Group Name	Name of user group
Role Group Domain	Domain of user group
Role Group Privilege	BMC access privilege setup of user group

Advanced Audit Log

To select Advanced Audit Log, the system will enter the interface in the figure 3-86.

Figure 3-86 Advanced Audit Log interface

Table 3-67 Description of Advanced auditing log setup interface

Information items	Description
BMC Audit Log	To click the button Download , a user can download BMC auditing log. To click the button Clear , a user can clear BMC auditing log.
SD Card Audit Log	When the mainboard is inserted with the SD card, a user can check the checkbox before Enable to enable auditing log of the SD card; After it is enabled, to click the button Download , a user can download audit log of SD card. To click the button Clear , a user can clear the audit log of the SD card.
Remote Audit Log	To check the checkbox before Enable , a user can enable the remote log function
Server Address	IP address of remote file server
Source Path	Sharing directory of file server
Share type	Sharing type, NFS or Samba (CIFS) are optional. Only when the latter is selected, the late three items will be set.
Username	Input user name of Samba(CIFS)
Password	Input user password
Domain Name	Input domain name

DNS

To select DNS, you can enter the DNS interface shown as the figure 3-87.





Figure 3-87 DNS interface

Table 3-68 Description of DNS setup interface

Information items	Description
DNS Service	Check the checkbox before Enable and enable DNS setting
mDNS Settings	Check the checkbox before Enable and enable Mdns
Host Settings	Set the acquisition method of the host name and select Automatic or manual. Only when Manual is select, the late Host name can be set
Host Name	Host name. When Manual is selected for Host Settings, you can input the host name here.
Register BMC	Register BMC, you can respectively register the special management interface and sharing network port
TSIG Authentication	Check the checkbox before Enable and enable TSIG function and permit BMC to update DNS server records.
Current TSIG Private File	Current TSIG private file, which is used to validate identity when DNS record is updated
New TSIG Private File	Update new private file
Domain Settings	Domain name setting
Domain Name	Set domain name. only when Domain Settings is set as Manual, this item can be set
DNS Server Settings	Domain name server setup
IP Priority	IP protocol priority setup
DNS Server1 DNS Server2 DNS Server3	IP address of DNS server, only when DNS Server Setting is set as Manual, this item can be set.

Event Log

To select Event Log, you can enter the interface shown as the figure 3-88.



This interface can set the event log strategy and the linear log strategy or cycle log strategy are optional.

LDAP/E-Directory

To select LDAP/E-Directory, you can enter the interface shown as the figure 3-38.




Figure 3-88 LDAP/E-Directory interface

To click the button **Advanced Settings**, the interface displays, shown as the figure 3-89.




Figure 3-89 Advanced LDAP setup interface


Table 3-69 Description of advanced LDAP setup interface

Information items	Description
LDAP/E-Directory Authentication	Check checkbox before Enable and enable LDAP/E-Directory function
SSL	Check checkbox before Enable and enable SSL to enhance data security

Server Address	IP address of LDAP/E-Directory server
Port	Service port number
Bind DN	Set distinction name for BMC bonding. The distinction name is used to mark one object
Password	Bond password of distinction name
Search Base	Set searched root directory
Attribute of User Login	Attribute for user login

Mouse Mode

To select ME Power Policy, you can enter the interface shown as the figure 3-90.



Mouse Mode

To select Mouse Mode, you can enter the mouse mode shown as the figure 3-90.

On this interface, you can change the setting for mouse mode of the redirection console, including absolute mode, relative mode and other. When the server runs on Windows, the absolute mode is recommended. When the server runs on Linux, the relative mode is recommended. When the server runs on SLES 11, other mode is recommended.




Figure 3-90 Mouse mode interface

Network

To select the network, you can enter the management network setup interface shown as the figure 3-91.

You can set the dedicated management network interface and sharing management network interface on this interface, including IPv4 setup, IPv6 setup and virtual LAN setup. You can click the button **Save** to save setting and the button **Reset** to reset.




Figure 3-91 Management network setup interface


Table 3-70 Network setup interface information

Information items	Description
LAN Interface	Network management mode: according to the different system, it offers different option as below : Dedicate: only use dedicate Ethernet port Share 1G: only use share 1G Ethernet port Share 10G:only use share 10G Ethernet port Failover- 1G : use the dedicate Ethernet port and share 1G Ethernet port at the same time by supporting Failover function. Failover -10G : use the dedicate Ethernet port and share 10G Ethernet port at the same time by supporting Failover function.
LAN Settings	Network configuration, select "Enable" box to enable this port.
MAC Address	Display MAC address, which can not be changed.
IPv4(6) Configuration	IPv4 (6) configuration
Obtain an IP address automatically	Automatically acquire IP address by selecting this box. Ethernet port will automatically acquire IP via the DHCP (dynamic host configuration protocol) server. Only when the box is not selected, the other three items can be configured.
IPv4(6) Address	Set IPv4(6) address
Subnet Mask (Subnet Prefix length)	Set sub-network mask (sub-network prefix length)
Default Gateway	Set default gateway

Network Bond

To select Network Bond, you can enter the network bonding setup interface, shown as the figure.

Figure 3-92 Network bonding setup interface



Check the checkbox after “Network Bonding” and enable network bonding. After the network bonding is enabled, you can check the checkbox after the Auto Configuration to enable automatic setting.

NTP

To select NTP, you can enter the NTP setup interface shown as the figure 3-93. NTP (network time protocol) is a protocol to synchronize the computer time.

The following information can be set on this interface, including date (MM-DD-YY), time (HH-MM-SS), time zone and NTP server.

To check “Automatically synchronize Date & Time with NTP Server” under the page, it indicates to automatically synchronize time and data with NTP server. At this time, only later two items are set. When it is unchecked, the previous three items are set. NTP Server item can not be set.

Figure 3-93 NTP setup interface

PEF

To select PEF, you can enter the PEF management interface shown as the figure 3-94. You can set the event filter, alert policy and LAN destination on this interface.

Figure 3-94 PEF management interface

PEF ID	Filter Configuration	Event Filter Action	Event Severity	Sensor Name
1	Enabled	[Alert]	Unspecified	Any
2	Enabled	[Alert]	Unspecified	Any
3	Enabled	[Alert]	Unspecified	Any
4	Enabled	[Alert]	Unspecified	Any
5	Enabled	[Alert]	Unspecified	Any
6	Enabled	[Alert]	Unspecified	Any
7	Enabled	[Alert]	Unspecified	Any
8	Enabled	[Alert]	Unspecified	Any
9	Enabled	[Alert]	Unspecified	Any
10	Enabled	[Alert]	Unspecified	Any
11	Enabled	[Alert]	Unspecified	Any
12	Enabled	[Alert]	Unspecified	Any

Table 3-71 Description of Event Filter item information

Information items	Description
PEF ID	PEF number (1, 2, 3....)
Filter Configuration	Filter configuration
Event Filter Action	Specific action for event filter
Event Severity	Event severity
Sensor Name	Sensor name

Table 3-72 Description of Alert Policy item information

Information items	Description
Policy Entry	Number regulated for alert (1, 2,3...)
Policy Number	Regulated number
Policy Configuration	Regulated configuration
Policy Set	Regulated setting
Channel Number	Channel number
Destination Selector	Destination selection

Table 3-73 Description of LAN Destination item information

Information items	Description
LAN Destination	Network destination number (1, 2, 3...)
Destination Type	Destination type
Destination Address	Destination address

To delete or change an item, you can select this item and click the button **Modify** or **Delete**. To add an item, you can select blank item and then click the button **Add** for addition.

To select Add or Modify in Event Filter item, the following setup interface will display.

The screenshot shows a web-based configuration interface for adding an event filter. The title bar reads "Add Event Filter entry". The main content area is organized into sections:

- Event Filter Configuration:**
 - PEF ID: 16
 - Filter Configuration: Enable
 - Event Severity: Unspecified
- Filter Action configuration:**
 - Event Filter Action: Alert
 - Power Action: None
 - Alert Policy Number: 1
- Generator ID configuration:** (This section is partially visible at the bottom of the form).

Figure 3-95 Event Filter addition interface -1

Generator ID configuration

Generator ID Data Raw Data

Generator ID 1

Generator ID 2

Event Generator Slave type Software type

Slave Address/Software ID

Channel Number

IPMB Device LUN

Sensor configuration

Figure 3-96 Event Filter addition interface -2

Sensor configuration

Sensor Type

Sensor Name

Event Options

Event Data configuration

Event Trigger

Event Data 1 AND Mask

Event Data 1 Compare 1

Figure 3-97 Event Filter addition interface -3

Event Data 1 Compare 2

Event Data 2 configuration

Event Data 2 AND Mask

Event Data 2 Compare 1

Event Data 2 Compare 2

Event Data 3 configuration

Event Data 3 AND Mask

Event Data 3 Compare 1

Event Data 3 Compare 2

Figure 3-98 Event Filter addition interface -4

Table 3-74 Description of Event Filter addition item

Addition items	Description
Event Filter Configuration	Event filter configuration
PEF ID	PEF SN, which can not be changed
Filter Configuration	Filter configuration. To select Enable, this function is enabled.
Event Severity	Event severity, including non-defined, monitoring, information, normal, non-critical, critical and non-recoverable. Option: [Unspecified]/[Monitor]/[Information]/[Normal]/[Non-Critical]/[Critical]/[Non-Recoverable]
Filter Action	Filter action configuration

configuration	
Event Filter Action	Event filter action. The checkbox before Alert is checked and can not be unchecked.
Power Action	Power action, including no action, close, restart and cycle Option: [None]/[Power Down]/[Power Reset]/[Power Cycle]
Alert Policy Number	Alert policy number, 1-15 are optional
Generator ID Data	Generate ID data. To select Raw Data, it indicates to select the original data.
Generator ID 1(2)	ID1(2)
Event Generator	Event generation, you can select slave address or system software ID Option: [Slave Address]/[System Software ID]
Channel Number	Channel number (0-15 are optional)
IPMB Device LUN	(1-3 are optional)
Sensor configuration	Sensor configuration
Sensor Type	Sensor type
Sensor Name	Sensor name
Event Options	Event option
Event Data configuration	Event data configuration
Event Trigger	Event trigger

To select Add or Modify in Alert Policy, the interface displays, shown as the figure 3-99.

Figure 3-99Alert Policy addition item interface

Table 3-75 Description of Alert Policy addition item

Addition items	Description
Policy Entry	Regulated alert number (1, 2, 3...)
Policy Number	Regulated number (1-15 are optional)
Policy Configuration	Regulated configuration, a user can select Enable or does not select
Policy Set	Regulated setting (0-4 are optional)
LAN Interface	Select management network interface
Destination Selector	Destination selection (1-15 are optional)
Alert String	Alert string, which can be selected as a special event.
Alert String Key	Key value of alert string (0-127 are optional)

To select Add or Modify in LAN Destination, the interface displays, shown as the figure 3-100.

Add LAN Destination entry

LAN Channel Number: 1

LAN Destination: 1

Destination Type: Snmp Trap

Destination Address: [Empty]

Username: anonymous

Subject: [Empty]

Message: [Empty]

[Add] [Cancel]

Figure 3-100 LAN Destination addition item interface

Table 3-76 Description of LAN Destination addition item

Addition items	Description
LAN Channel Number	Network channel number
LAN Destination	Network destination number, which can not be changed
Destination Type	Destination type. Trap alert and mail alert are optional. When Trap alert is selected, the Destination Address can be set. When the mail alert is selected, the Username, Subject and Message can be set. Option: [Snmp Trap]/[Email Alert]
Destination Address	SNMP Trap alert receiving address
Username	User name, which is selected from all BMC users
Subject	Title of alert mail
Message	Attached contents of alert mail

RADIUS

To select RADIUS, you can enter the interface, shown as the figure 3-101.

RADIUS Settings

The RADIUS Authentication is currently disabled. To enable RADIUS Authentication and enter the required information to access the RADIUS server. Press the Save button to save your changes. To configure the Advanced settings, RADIUS Server authentication should be enabled.

[Advanced Settings]

RADIUS Authentication: Enable

Port: 1812

Server Address: [Empty]

Secret: [Empty]

Extended privileges: KVM VMedia

[Save] [Reset]

Figure 3-101 RADIUS interface

Table 3-77 Description of RADIUS setup interface

Addition items	Description
RADIUS Authentication	Check checkbox before Enable and enable RADIUS authentication function
Port	Service port number
Server Address	IP address of RADIUS server
Secret	Password
Extended privileges	Expansion privilege. Check the checkbox before the

corresponding item and grant corresponding privilege.

Remote Session

To select Remote Session, you can enter the remote session interface as the figure 3-102.



Figure 3-102 Remote conference interface

Table 3-78 Remote Session interface information item

Information items	Description
Single Port Application	Single-port application. To check this item, the setting of the following two items will be hidden.
KVM Encryption	KVM encryption
Media Encryption	Media encryption
Keyboard Language	Keyboard language selection
Virtual Media Attach Mode	Virtual media connection mode
Local Monitor Off	Local monitor off
Automatically OFF Local Monitor , When JViewer Launches	When JViewer starts, the local monitoring will automatically turn off

SMTP

To select SMTP, you can enter the SMTP interface shown as the figure 3-103. The SMTP indicates Simple Mail Transfer Protocol and is a group of rules to transfer mails from the source address to destination address. It can control forwarding mode of the mails.

Figure 3-103 SMTP interface

Table 3-79 Description of SMTP interface information

Information items	Description
LAN Channel Number	Select channel number
Sender Address	Sender address
Machine Name	Machine name
Primary SMTP Server (Secondary SMTP Server)	Master SMTP server (slave SMTP server) setting
SMTP Support	Enable SMTP support
Port	Set service port number
Server Address	Server address
SMTP Server requires Authentication	SMTP server should be validated and can be set by selecting the front checkbox
User Name	User name
Password	Password

SSL

To select SSL, the system will enter the SSL authentication configuration interface shown as the figure 3-104. This item includes Upload SSL, GenerateSSL and View SSL.




Figure 3-104 SSL authentication configuration interface

Upload SSL

To select Upload SSL, you can originate SSL upload, shown as the figure 3-104. The first two items are the current certificate and current key in the following information items. To click the button **浏览...**, select a new SSL certificate, and click the button **Upload**, you can upload it.

Generate SSL :



Figure 3-105 Generate SSL item interface

To select Generate SSL, you can generate SSL, shown as the figure 3-105. Fill corresponding information and select the button **Generate** for generation.

Table 3-80 Description of Generate SSL interface information

Information items	Description
Common Name(CN)	General name
Organization(O)	Organization
Organization Unit(OU)	Organization unit
City or Locality(L)	City or area
State or Province(ST)	State or province
Country(C)	State
Email Address	Email address
Valid for	Valid period

Key Length	Key length, 512 and 1024 are optional
------------	---------------------------------------

View SSL




Figure 3-106 View SSL item interface

To select View SSL, you can view SSL information, including basic information (version, SN, algorithm and public key), release information, valid time and sending address.

System and Audit Log

To select System and Audit Log, you can enter the system and audit log setup interface shown as the figure 3-107.




Figure 3-107 System and audit log setup interface

Table 3-81 Description of system and audit log setup interface information

Information items	Description
System Log	Check the later checkbox to enable system log
Log Type	To select local mode, you should set the following File size and Rotate Count parameter. To select remote mode, you should set the Server Address parameter
File Size(in bytes)	Size of local log file (with byte as the unit)
Rotate Count	Cycle time
Server Address	Address of remote log server
Audit Log	Check the later checkbox to enable audit log

System Firewall

To select System Firewall, you can enter the system firewall interface shown as the figure 3-108.




Figure 3-108 System firewall setup interface

This interface includes two label tabs, including IP Address and Port. The IP Address tab displays the IP address policy. To click the button **Add** at the right low corner, you can add a new IP address strategy, shown as the figure 3-109. Select an item and click the button **Delete** for deletion.



Figure 3-109 IP address policy addition interface

The IP/IP Range item is used to set the IP address (range). The IP Settings item is used to set the policy for above IP address (range). Allow or block are optional.

The Port page displays the policy for the port. To click the button **Add** at the right and low corner, you can add new port policy, shown as the figure 3-110.

To select an item and click the button **Delete**, you can delete it.




Figure 3-110 Port policy addition interface

Port/Port Range item is used to set the port number (range). The Protocol item is used to select the transfer protocol. TCP or UDP are optional. Port Settings is used to set the port policy. Allow or block are optional.

To click the button **Advanced Settings** at the right up corner, you can uniformly set it, shown as the

figure 3-111.




Figure 3-111 Advanced setup interface

Check Block All and forbid all access.

【Notice】 Please check this item carefully. To check it, you can not access the management network interface!

Check Flush All, all access are permitted.

Users

To select Users, you can enter the user management interface shown as the figure 3-112.




Figure 3-112 Users interface

To check existing item and click the button **Modify User** or select the blank item, and click the button **Add User**, the interface will display, shown as the figure 3-113. To the existing item and click the button **Delete User**, the user can be deleted.

Figure 3-113 User addition interface

Table 3-82 Description of user information item addition

Information items	Description
Username	User name
Password Size	Password length, 16 digits and 20 digits are optional
Password	To select the checkbox before Change Password, you can reset the password.
Confirm Password	Confirm the password and keep it consistent with Password
User Access	Select Enable, which indicates to allow user access.
Network Privilege	Select the network privilege, including administrator, operator, user, OEM owner and no privilege. Option: [Administrator]/[Operator]/[User]/[OEM Proprietary]/[No Access]
Extended Privilege	Expansion privilege, KVM and Vmedia are optional
SNMP Status	Check the later checkbox to enable the SNMP privilege and then set the latter three items.
SNMP Access	Set SNMP read/write privilege, option: [Read Only]/[Read Write]
Authentication Protocol	Set authorized agreement. Option: [SHA]/[MD5]
Privacy Protocol	Set encryption agreement: Option: [DES]/[AES]
Email ID	Set user mailbox address
Email Format	Set format of user email, option: [AMI-Format]/[Fixed Subject-Format]
New SSH Key	New SSH key. To click "Browse", you can select it

After setting, to click the button **Add** or **Modify** at the right low corner, you can add/change user.

Virtual Media

To select Virtual Media, you can enter the virtual media device interface shown as the figure 3-114. The following options will allow to configure the number of supported virtual media devices, including floppy device, CD device and hard disk device.




Figure 3-114 Virtual Media interface

User Lock Settings

To select User Lock Settings, you can enter the user lock interface shown as the figure.



Figure 3-115 User lock setup interface

This interface can set the maximum time of continuous incorrect password input for the user. After this limit is exceeded, the user will be locked. It can also set the user lock time. To click the button **Save** , you can save setting. To click the button **Reset** , you can reset.

3.4.6 Remote Control

To click Remote Control menu, the following sub-menu will occur, shown as the following figure.



Figure 3-116 Remote control sub-menu

Console Redirection

To select Console Redirection item, you can redirect the console, shown as the figure 3-117.




Figure 3-117 Console Redirection interface

To click the button **Java Console**, you can operate as the prompt and enable the remote console window (JRE software package should be installed), shown as the figure 3-118.




Figure 3-118 Redirection interface

This remote console includes many menus, can perform many settings, and realize many functions. Here only several frequent functions are introduced.

Remote mounting of mirroring file/hard disk/U disk/CD/floppy driver:

To select Virtual Media Wizard submenu under Media menu, the interface will pop up, shown as the figure 3-119.




Figure 3-119 Virtual media mounting interface

On this figure, Flop Key Media area can mount floppy disk or floppy drive (when the PC provides the floppy drive). To mount the image, you should click Browse. You should find and select the mirroring file to mount and then click the right “Connect Floppy” button.

The CD/DVD Media area can mount the CD image in a manner as the floppy drive image and can mount the CD ROM. You should select the CD ROM symbol (G in the figure) and then click “Connect CD/DVD” button.

Hard disk/USB Key Media area can mount ima and img mirroring files or mount the local hard disk or U disk (when the PC includes U disk). The mounting method is same as the above mirroring and CD ROM.

Snapshot function

Shown as the figure 3-120, to select Capture Screen sub-menu under Video menu or use Alt+S shortcut key, you can cut the interface on the current console. To select the file saving location on the pop-up file saving dialog and set the file name and click “Save”, you can save the file.




Figure 3-120 Video sub-menu

The full keyboard supports enable function:

You can use the keyboard on the redirection console, but the combination key is not supported by default. If the combination key is expected, you can check the checkbox before Full Keyboard Support under Keyboard menu.




Figure 3-121 Keyboard sub-menu

Enable soft keyboard:

To select SoftKeyboard sub-menu under the Keyboard Layout menu, the keyboard with different language layouts will pop up. To select the required keyboard, you can open the virtual keyboard.




Figure 3-122 Keyboard Layout sub-menu

Video recording function

To select the Settings sub-menu under Video Record menu, the video recording setup interface will pop up, shown as the figure 3-124.




Figure 3-123 Video Record sub-menu




Figure 3-124 Video recording setup interface

On this figure, you can set the maxim recording length of the video. To click Browse, you can select the location for automatically saving the video. After setting, you can set “OK” and save this

setting. At this time, you can Start Record and Stop Record under Video Record menu to control video recording. After recoding, the video file will be automatically generated.

Server power control:

To select Power menu, its sub-menu is shown as the figure 3-125.




Figure 3-125 Power sub-menu

To select Reset Server, you can restart the server. To select Immediate Shutdown, the server will instantly shut down. To select Orderly Shutdown, the power-off command will be sent to the server. To select Power Cycle Server, the server will power off and then power on. When the server powers off, the Power On Server is optional. To select it, the server will start.

Server Power Control

To select Server Power Control, you can view the current state, shown as the figure 3-126. To select proper options on demand and click the button , you can realize the operation. The current status will display corresponding contents.




Figure 3-126 Power Control and Status

Table 3-83 Description of Power option

Power control item	Description
Host is currently off	Display current host status in real time
Reset Server	Restart server
Power Off Server - Immediate	Instantly shut down server
Power Off Server – Orderly Shutdown	Send power off command to the server

Power On Server	Start server
Power Cycle Server	Cut off the server DC and power off
Power Button	Power button

Java SOL

To select Java SQL, you can redirect the serial port, shown as the figure 3-127.



Figure 3-127 Java SOL interface

To click the button **Java SOL**, you can operate and open the serial port to redirect the window according to prompt and the setup interface pops up, shown as the figure 3-128.




Figure 3-128 Serial port redirection setup interface

Table 3-84 Description of serial port redirection setup interface

Power control item	Description
BMC IP	IP address of BMC
Username	BMC user name
Password	BMC user password
Volatile-Bit-Rate	Volatile bit rate
Non-Volatile-Bit-Rate	Non-volatile bit rate

To correctly fill the corresponding information and click the button **Connect**, you can connect.

To click Session, the following figure is shown.




Figure 3-129 Session sub-menu

To Close SQL Session, you can close the current SQL session. To select Open SQL Session, you can open a new SQL session.

ID LED Control

To select ID LED Control, the ID lamp control interface is shown as the figure 3-130.




Figure 3-130 ID control interface

You can select to turn on ID lamp, turn off ID lamp and turn on ID lamp and then turn off after a period on this interface. The third item can be set with the on time. After it is selected, you can click the button **Perform Action** and execute the operation.

Power Button Control

To select Power Button Control, the power button setup interface displays, shown as the figure 3-131.




Figure 3-131 Power button setup interface

This interface can disable/enable the power button. After it is enabled, the power button on the device will not take effect.

FAN Control

To select FAN Control, you can enter the fan policy setup interface shown as the figure 3-132.




Figure 3-132 Fan policy setup interface

On this interface, you can set the fan policy as the balance mode, high performance mode, silence mode, full-speed mode and half-speed mode.

BIOS First Boot Device Selector

To select BIOS First Boot Device Selector, you can enter the BIOS first start item selection interface shown as the figure 3-133.




Figure 3-133 BIOS first start item selection interface

On this interface, you can set the first start item when the device restarts next time and will not change the start sequence setting in BIOS.

3.4.7 Auto Video Recording

To click Auto Video Recording menu, the automated video recording sub-menu will display, shown as the figure 3-134.



Figure 3-134 Automated video recording sub-menu

Triggers Configuration

To select Triggers Configuration, you can enter the trigger condition setup interface shown as the

figure 3-135.




Figure 3-135 Trigger condition setup interface

Table 3-85 Description of trigger condition

Power control item	Description
Temperature/Voltage Critical Events	Temperature/voltage critical alert event
Temperature/Voltage Non Critical Events	Temperature/voltage non-critical alert event
Fan State Changed Events	Fan status change event
Watchdog Timer Events	Watchdog timer event

To tick the corresponding trigger condition and click the button **Save**, you can save the settings.

Recorded video

To select Recorded Video, the recorded list interface will display as the figure 3-136.




Figure 3-136 Recorded video list interface

This interface display the recorded video list (display no video on the figure). To select the video and click the button at the right low corner, you can play, download and delete video.

3.4.8 Maintenance

To click Maintenance menu, the sub-menu will display as the following figure.




Figure 3-137 Maintenance sub-menu

Preserve Configuration

To select Preserve Configuration, the setup interface for keep existing configuration will display, shown as the figure 3-138.




Figure 3-138 Setup interface for keeping existing configuration

On this interface, you can set the configurations which are saved and are not reset in case of factory setting recovery or firmware refreshing. To check the checkbox after the configuration to save and click the button **Save**, you can save the setting.

Restore Configuration

To click Restore Configuration, you will enter the factory setting recovery interface, shown as the figure 3-139.




Figure 3-139 Factory setting recovery setup interface

This interface lists the non-rest items set in Preserve Configuration. To click the button **Enter Preserve Configuration**, you can enter the Preserve Configuration menu. To reset the items to save and click the button **Restore Configuration**, all other BMC settings except items in the above list will be reset.

【Notice】 To enter factory setting recovery interface, other webpages and services will not work. All opened windows will automatically close. This device will reset and restart within several minutes.

3.4.9 Firmware Update

To click Firmware Update menu, the sub-menu displays, shown as the following figure.




Figure 3-140 Firmware Update sub-menu

Firmware Update

To select Firmware Update sub-menu, you can enter the BMC firmware upgrade interface, shown as the figure 3-141.




Figure 3-141 BMC firmware upgrade interface

This interface lists all configurations which are changed or saved in firmware refreshing. To click the button **Enter Preserve Configuration**, you can enter Preserve Configuration menu and set the configuration to save. To click the button **Enter Update Mode**, you will enter BMC refreshing mode and upload BMC file as the prompt. The interface will display, shown as the figure 3-142.




Figure 3-142 Selection interface of BMC firmware upgrade and refreshing module

This interface can be used to refresh some modules. To check the items to refresh on the right list

and click the button **Proceed**, you can refresh it. To check “Version Compare Flash”, only the modules with updated versions are refreshed. To check “Full Flash”, all modules can be refreshed.

To click the button **Cancel**, you can cancel refreshing. BMC device will restart.

【Notice】 To enter the update mode, other webpages and service can not work. All opened windows will automatically close. If upgrade process is cancelled in guidance, this device will be reset.

BIOS Update

To select BIOS Update, you will enter the BIOS firmware refreshing interface, shown as the figure 3-143.




Figure 3-143 BIOS firmware refreshing interface

If the machine is under the power on status, the alert box will pop up, shown as the figure 3-144.




Figure 3-144 BIOS firmware refreshing alert interface

The alert box prompts “the server is under power on status, please shut down the server”. This mode will refresh BIOS firmware when the server is under power off status, please refresh when the server powers off.

After the server powers off, to click the button **Start Updating BIOS**, the system will enter the BIOS refreshing mode. After BISO file is uploaded according to the prompt, refreshing will start.

【Notice】 To enter BIOS refreshing mode, other webpages and service can not work.

4 OS installation guide

This guide includes the following OS, including Windows 2008 Enterprise Server and Red Hat Enterprise Linux6 update.

4.1 Windows 2008 Enterprise Server R2 SP1 64bit

Installation steps:

Step 1: Power on, place the CD marked with “Microsoft Windows 2008 Server” into the CD ROM, and boot from the CD.

Step 2: Select installation language, time and keyboard layout and then click “Next”.

Step 3: Click “Install now” and start to install it.

Step 4: Display SN input interface, correctly input the SN according to the prompt, and click “Next”.

Step 5: Next select the 2008 server version to install. With Windows Server 2008 Enterprise as the example, check the prompt “I have selected the edition of Windows that I purchased” under the screen, and click “Next”.

Step 6: Check “I accept the license terms” on the webpage and click “Next”.

Step 7: Select “Custom” mode on the displaying interface and install it.

Step 8: If the user is not configured with RAID card, you can directly install it on the hard disk partition. If RAID card is configured, you should select “Load Driver” and load the driver of the corresponding RAID card.

Step 9: After configuration is completed, to click “Next”, the system installation will start.

Step 10: The system will automatically restart during installation. After tens of minutes, the system installation is completed and the user password should be configured.

Note: The Windows 2008 password should include English letters, numbers and symbols.

Step 11: After completion, a user can normally use Windows 2008 Server OS.

Note: A user may load drivers for some external plug-in cards.

4.2 Red Hat Enterprise Linux AS 6 Update 2 X86_64

Installation steps

Step 1: Power on, place the CD marked with “Redhat Linux Advanced Server 6 Update 2(64bit) DVD” into the CD ROM, and start from CD. If requested, please load the floppy disk driver via linux dd mode.

Step 2: To select “Skip”, you can skip the detection CD. If the user wants to detect integrity of the system CD, he can select “OK”.

Note: It will spend much time in detecting the CD, please wait for it patiently.

Step 3: After detection is completed, click “Next” on the interface.

Step 4: A user selects the required language on the language selection interface and click “Next”.

Step 5: Select the corresponding keyboard layout on the keyboard layout configuration interface and then click “Next”.

Step 6: Next input the SN according to the prompt. A user can input the SN according to the requirements.

Step 7: Initialize the hard disk data according to the requirements, select “Yes” and click “Next”.

Step 8: When the hard disk partition configuration interface displays, a user can select the corresponding hard disk and create different partitions. With one hard disk as one example, select “Create Custom layout” and click “Next”.

Step 9: A user can create different partitions on demand in this step. Create the root partition, /boot partition and swap partition and click “Next”.

Step 10: Select if the boot loader is installed and click “Next” on “Boot Loader Configuration” interface.

Step 11: Select and configure IP acquisition mode of the network card, configure the Hostname of the host, and click “Next”.

Step 12: Select “Asia/Shanghai” and click “Next” on the time zone selection interface.

Step 13: Input root administrator password at “Root Password” field, input it at “Confirm” field, and confirm it on the root account password setup interface. The administrator password should include at least 6 digits.

Step 14: When the software package is installed, you should check “Customize now” and click “Next”.

Step 15: Select the installation package and click “Next” on the interface.

Step 16: To wait for the installation procedure, check association of the installation package and then click “Next”, the system installation starts.

Step 17: After installation ends, click “Reboot”.

Step 18: Display configuration interface and select “Forward”.

Step 19: Select accept and click “Next” on the “License Agreement” interface.

Step 20: Configure if the firewall is enabled on “Firewall” interface and click “Next”.

Step 21: At this time, the “SELinux” configuration interface will display. You should set the corresponding level and click “Forward”.

Step 22: A user sets Kdump on demand and clicks “Next”.

Step 23: Set date and time and click “Next”.

Step 24: Register product and operate according to the interface prompt.

Step 25: A user (non-root account user) can create account on demand and click “Next”.

Step 26: Select to install some software packages of other CD on the “Additional CDs” page.

Step 27: To click “Finish” and restart button, you can use Red Hat Enterprise Linux 6 Update 2 system.

5 FAQ of products

Default start sequence of system

USB device, built-in CD, built-in hard disk, front hard disk, external network card PXE, onboard PXE

How to read the remote management URL

- When the switcher network is used, you should connect the network cable to the rear IPMI management interface of the chassis and read BMC IP address via the front panel, or you should enter the BIOS management interface and read BMC IP under BMC network configuration. If no address is available, the network configuration mode is selected as [Dynamic-Obtained by BMC]. Press F4 to save, restart and try again.
- When the direct connection mode is used, after the network cable is connected to IPMI management interface, you will enter BIOS, select the network configuration mode as Static under BMC network configuration, manually input IP address and gateway, press F4 to save and restart.

How to install GPU or external plug-in display card provided by Sugon

Please confirm if the GPU or external plug-in display card connects the external power supply. If it is required, please contact Sugon after-sale personnel for assembly. First, set the VGA Priority option in BIOS as the offboard, save it and restart. At this time, the video will be outputted via VGA.

Appendix I Abbreviations

Abbreviations	Explanation
BIOS	Basic input/output system
BPS	Bit/sec (BIT PER SECOND)
CMOS	COMPLEMENTARY METAL OXIDE SEMICONDUCTOR
CPU	CENTRAL PROCESSING UNIT
DIMM	DUAL IN-LINE MEMORY MODULE
DMA	DIRECT MEMORY ACCESS. DMA channel can make some data bypass the processor and directly transfer between RAM and device
DRAM	DYNAMIC RANDOM ACCESS MEMORY. Generally computer's RAM is composed of DRAM chip.
ECC	ERROR CHECKING AND CORRECTION

EMC	ELECTRO MAGNETIC COMPATIBILITY
EMI	ELECTRO MAGNETIC INTERFERENCE
ESD	ELECTRO STATIC DISCHARGE
FAT	FILE ALLOCATION TABLE
FTP	FILE TRANSFER PROTOCOL
GB	GIGABYTE. One GB is equal to 1024MB or 1,073,741,824 bytes.
Hz	HERTZ
I/O	INPUT/OUTPUT
IP	INTERNET PROTOCOL
IRQ	INTERRUPT REQUEST. It is a signal sent to the bit process via IRQ line and indicates that the peripheral device will send or receive data.
KB	KILOBYTE, namely 1024 bytes
LAN	LOCAL AREA NETWORK
LCD	LIQUID CRYSTAL DISPLAY
LED	LIGHT EMITTING DIODE, it is an electronic device which will give out light when the current passes it.
LUN	LOGICAL UNIT NUMBER
MB	MEGABYTE, which indicates 1,048,576 bytes
MBR	MASTER BOOT RECORD
MHz	MEGA HERT Z
MTBF	MEAN TIME BETWEEN FAILURES
NIC	NETWORK INTERFACE CONTROLLER
NTFS	FILE SYSTEM
PCI	PERIPHERAL COMPONENT NTERCONNECT
POST	POWER-ON SELF-TEST. Before the device powers on and loads the OS, POST will detect different components
RAM	RANDOM ACCESS MEMORY, namely the memory
ROM	READ ONLY MEMORY
SDRAM	SYNCHRONOUS DYNAMIC RANDOM ACCESS MEMORY
SNMP	SIMPLE NETWORK MANAGEMENT PROTOCOL
TCP/IP	TRANSMISSION CONTROL PROTOCOL/INTERNET PROTOCOL
UPS	UNINTERRUPTED POWER SUPPLY
USB	UNIVERSAL SERIAL BUS

Appendix II POST code check point of LCD

The POST code check point is the maximum check point set of BIOS pre-booting. The following table describes the type of the possible check points of BIOS POST.

Scope of check points

Scope of status code	Description
0x01 – 0x0B	Execute SEC
0x0C – 0x0F	Sec error
0x10 – 0x2F	PEI execution ends at the memory test
0x30 – 0x4F	PEI error
0x50 – 0x5F	DXE executes BDS
0x60 – 0x8F	Execute BDS
0x90 – 0xCF	DXE error
0xD0 – 0xDF	S3 restart (PEI)
0xE0 – 0xE8	S3 restart error (PEI)
0xE9 – 0xEF	Recovery (PEI)
0xF0 – 0xF8	Recovery error (PEI)
0xF9 – 0xFF	

Standard check point

SEC phase

SEC phase	Description
0x00	Careful operation
Process cod	Description
0x01	Start, reset test (soft/hard)
0x02	Initialize AP before micro-code is loaded
0x03	Initialize north bridge before micro-code is loaded
0x04	Initialize south bridge before micro-code is loaded
0x05	Initialize OEM before micro-code is loaded
0x06	Load micro-code
0x07	Initialize AP after micro-code is loaded
0x08	Initialize north bridge after micro-code is loaded
0x09	Initialize south bridge after micro-code is loaded
0x0A	Initialize OEM after micro-code is loaded
0x0B	Initialize high-speed cache
SEC error code	Description

0x0C – 0x0D	Reserve code of possible AMI SEC error
0x0E	No micro code found
0x0F	No micro code found

PEI phase

Status code	Description
Process code	Description
0x10	PCI core start
0x11	Pre-memory initialization started
0x12	Pre-memory CPU initialization (CPU module embodiment)
0x13	Pre-memory CPU initialization (CPU module embodiment)
0x14	Pre-memory CPU initialization (CPU module embodiment)
0x15	Pre-memory north bridge initialization started
0x16	Pre-memory north bridge initialization (north bridge module embodiment)
0x17	Pre-memory north bridge initialization (north bridge module embodiment)
0x18	Pre-memory north bridge initialization (north bridge module embodiment)
0x19	Pre-memory south and south bridge initialization started (south bridge module embodiment)
0x1A	Pre-memory south and south bridge initialization started (south bridge module embodiment)
0x1B	Pre-memory south and south bridge initialization started (south bridge module embodiment)
0x1C	Pre-memory south and south bridge initialization started (south bridge module embodiment)
0x1D - 0x2A	OEM pre-memory initialization code
0x2B	Memory initialization, which reads serial existence detection (SPD) data
0x2C	Memory initialization, memory existence detection
0x2D	Memory initialization, memory process time sequence information
0x2E	Memory initialization, memory configuration
0x2F	Memory initialization (Other)
0x30	ASL reserved

0x31	Memory installation
0x32	Start initialization after CPU memory configuration
0x33	High-speed cache initialization
0x34	Application initialization
0x35	Processor binding selection started
0x36	System management mode initialization (SMM)
0x37	Start North bridge initialization after memory configuration
0x38	North bridge configuration after memory configuration (specific north bridge module)
0x39	North bridge configuration after memory configuration (specific north bridge module)
0x3A	North bridge configuration after memory configuration (specific north bridge module)
0x3B	Start south bridge initialization after memory configuration
0x3C	South bridge configuration after memory configuration (specific south bridge module)
0x3D	South bridge configuration after memory configuration (specific south bridge module)
0x3E	South bridge configuration after memory configuration (specific south bridge module)
0x3F - 0x4E	OEM initialization code after memory configuration
0x4F	DXE PIL started
PCI error code	Description
0x50	Memory initialization error, invalid memory type or incompatible memory speed
0x51	Memory initialization error, SPD reading failure
0x52	Memory initialization error, invalid memory size and non-matched active memory module
0x53	Memory initialization error, no available memory detected
0x54	Memory initialization error not specified
0x55	Memory not installed
0x56	Invalid CPU type or speed
0x57	CPU self-test failure or possible CPU high-speed cache error
0x58	CPU micro-code or micro-code update failure not found
0x59	CPU micro-code not found or micro-code update failed
0x5A	Internal CPU error

0x5B	Reset PPI unavailable
0x5C - 0x5F	Further AMI error code reserved
S3 rebooting process code	Description
0xE0	S3 rebooting started (S3 rebooting PPI is controlled by DXE IPL)
0xE1	S3 power on script execution
0xE2	Video posting
0xE3	OS S3 wakeup vector called
0xE4 - 0xE7	Further AMI process code reserved
S3 rebooting error code	Description
0xE8	S3 rebooting failure
0xE9	S3 rebooting PPI not found
0xE A	S3 rebooting script error
0xE B	S3 OS wakeup error
0xE C - 0xEF	Future AMI error code reserved
Recovery process code	Description
0xF0	Recovery caused by firmware (automated recovery)
0xF1	Recovery caused by user (forced recovery)
0xF2	Recovery process started
0xF3	Firmware image found and recovered
0xF4	Firmware image loaded and recovered
0xF5 - 0xF7	Future AMI process code reserved
Code of recovery error	Description
0xF8	Invalid recovery PPI
0xF9	Recovery protection not found
0xFA	Invalid recovery protection
0Xfb - 0xFF	Future AMI error code reserved

PEI beeping code

Beeping time	Description
1	Memory not installed
1	Memory installed two time (process from PIE memory)

	installation to PIE core call executed two times)
2	Recovery started
3	DEX IPL not found
4	DXE core firmware volume not found
5	Recovery failure
6	S3 rebooting failure
7	Invalid PPI reconfiguration

DXE phase

Status code	Description
0x60	DXE core started
0x61	NVRAM initialization
0x62	Service in case of south bridge operation initialization
0x63	CPU DXE initialization started
0x64	CPU DEX initialization (specific CPU module)
0x65	CPU DEX initialization (specific CPU module)
0x66	CPU DEX initialization (specific CPU module)
0x67	CPU DEX initialization (specific CPU module)
0x68	PCI main bridge initialization
0x69	North DXE initialization started
0x6A	North bridge DXE SMM initialization started
0x6B	North bridge DXE initialization (specific north bridge module)
0x6C	North bridge DXE initialization (specific north bridge module)
0x6D	North bridge DXE initialization (specific north bridge module)
0x6E	North bridge DXE initialization (specific north bridge module)
0x6F	North bridge DXE initialization (specific north bridge module)
0x70	South DXE initialization started
0x71	South DXE SMM initialization started
0x72	South bridge device initialization
0x73	South bridge initialization (specific south bridge module)
0x74	South bridge initialization (specific south bridge module)
0x75	South bridge initialization (specific south bridge module)
0x76	South bridge initialization (specific south bridge module)
0x77	South bridge initialization (specific south bridge module)
0x78	ACPI module initialization
0x79	CSM initialization

0x7A - 0x7F	Further AMI DXE code reserved
0x80 - 0x8F	OEM DXE initialization code
0x90	Start device selection phase started (BDS)
0x91	Driver connection started
0x92	PCI bus initialization started
0x93	PCI bus hot plug controller initialization
0x94	PCI bus enumeration
0x95	PCI bus request resources
0x96	PCI bus configuration resource
0x97	Console output device connection
0x98	Console input device connection
0x99	Over IO initialization
0x9A	USB initialization started
0x9B	USB resetting
0x9C	USB detection
0x9D	USB started
0x9E - 0x9F	Further AMI code reserved
0xA0	IDE initialization started
0xA1	IDE resetting
0xA2	IDE detection
0xA3	IDE started
0xA4	SCSI initialization started
0xA5	SCSI resetting
0xA6	SCSI resetting
0xA7	SCSI detection
0xA8	SCSI started
0xA9	Validation password setting
0xAA	Installation started
0xAB	ASL reserved
0xAC	Input waiting setting
0xAD	ASL reserved
0xAE	Start ready event
0xAF	Old start event
0xB0	Exit from start service event
0xB1	Set virtual address mapping in case of operation start
0xB2	Set virtual address mapping in case of operation termination

0xB3	Old optional ROM initialization
0xB4	System resetting
0xB5	USB hotspare
0xB6	NVRAM clearing
0xB7	Configuration resetting (NVRAM setting reset)
0xB8 - 0xBF	AMI code reserved
0xC0 - 0xCF	OEM BDS initialization code
DXE error code	Description
0xD0	CPU initialization error
0xD1	North bridge initialization error
0xD2	South bridge initialization error
0xD3	Some invalid architecture protocol
0xD4	PCI resource allocation error, exceeding resources
0xD5	No space provided to optional ROM
0xD6	Console output device not found
0xD7	Console input device found
0xD8	Invalid password
0xD9	Error loading booting option (image loading error returned)
0xDA	Start option failure (image transfer start error)
0xDB	Flash memory update failure
0xDC	Invalid protocol resetting

DXE being code

Beeping time	Description
1	Invalid password
2	Some invalid constructed protocol
3	Control output device not found
4	Control input device found
5	Memory update failure
6	Invalid protocol reset
7	Platform PCI resources failing to meet requirements
8	

ACPI/ASL check point

Status code	Description

0x01	System enters S1 sleeping status
0x02	System enters S2 sleeping status
0x03	System enters S3 sleeping status
0x04	System enters S4 sleeping status
0x05	System enters S5 sleeping status
0x10	System wakes up from S1 sleeping status
0x20	System wakes up from S2 sleeping status
0x30	System wakes up from S3 sleeping status
0x40	System wakes up from S4 sleeping status
0xAC	System has transformed to ACPI mode. The interruption controller includes APIC mode
0xAA	System has transformed to ACPI mode. The interruption controller includes APIC mode

Appendix III RAID configuration description of onboard hard disk controller

Enter RAID card management interface

【Notice】 Raid configuration program may be upgraded and updated. The documents and figure in the appendix is only for reference. Refer to the actual products of users.

To start the system and input “Ctrl+ R” when the POST interface shows the prompt in the following figure, you enter the RAID card management interface, shown as the figure.

```

ID LUN VENDOR   PRODUCT                REVISION   CAPACITY
-- -- --
70 0  HGST       HUC156060CSS200      A12B      572325MB
@ Virtual Drive(s) found on the host adapter.

@ Virtual Drive(s) handled by BIOS
Press <Ctrl><R> to Run MegaRAID Configuration Utility
-

```

Figure 0-1 POST prompt interface




Figure 0-2 RAID management interface

“VD Mgmt” indicates “Virtual Drive Management” and aims to create and manage RAID array.

“PD Mgmt” indicates “Physical Drive Management” and aims to perform physical disk operations such as hard disk information view.

“Ctrl Mgmt” indicates controller management and can set the controller.

“Properties” indicates RAID card information and aims to view FW/BIOS/Model of RAID card.

Create RAID array:

To move the cursor to the controller column by using “↑↓” on “VD Mgmt” and input “F2” according to the bottom prompt, the following interface is shown.




Figure 0-3 Controller menu interface

To select “Create Virtual Drive”, you can enter the RAID creation interface, shown as the following figure.




Figure 0-4 RAID creation interface

Select level of RAID to create at the “RAID Level” column. If the RAID to create is RAID10/RAID50/RAID60, the “PD per Span” value should be set, namely number of hard disks included in each bottom RAID. An even number bigger than or equal to 2 can only be selected for RAID10.

A number bigger than or equal to 3 should be selected for RAID50/60.

Select the memory hard disk of RAID array. With RAID1 as the example in the figure, select the hard disk to add RAID by using “Space” key at Drives column.




Figure 0-5 Hard disk selection

Set the capacity and name of RAID array in “Basic Settings”.

to set the read/write policy, you should select “Advanced” for setting, shown as the following figure.




Figure 0-6 Advanced setup interface

Strip Size: generally it is a default value.

Read Policy: read policy of RAID array. It keeps the default value.

Write Policy: write policy of RAID array. “Write Through” indicates to directly write into the hard disk without the need of using the RAID chip cache. The performance of this policy is not high, but it will not lead to data loss in case of crash failure. “Write Back” will use the RAID chip cache, so it improves the performance. When no spare battery is available, the data in the cache will be lost due to accidental crash. “Write Back With BBU” will use “Write Back” policy when the spare battery is installed. When spare battery is not installed, “Write Through” is used.

I/O Policy: read/write policy, it keeps the default value.

Disk Cache policy: hard disk cache policy, it keeps the default value.

Initialize: to check the checkbox before it, the RAID array will be initialized. It will delete all data on the array.

Configuration hotspare: the redundant spare is configured. Other blank hard disks will be automatically used to replace the invalid hard disk when a hard disk in the array is invalid.

After setting, to select “OK”, you can save settings.

To select “OK” on the figure 0-5, you can complete RAID array configuration.

Delete RAID array:

RAID array will be deleted via the following three modes:

Mode 1: delete a specific Virtual Drive.

Move the RAID column under the Virtual Driver in Drive Group directory, input “F2” and select “Delete VD”.




Figure 0-7 Delete Virtual Drive

Mode II: delete all RAID arrays in Drive Group.

Move the cursor to the Drive Group column to delete, input “F2” and select “Delete Drive Group”.




Figure 0-8 Delete Drive Group

Mode III: Delete all RAID configuration information.

Move the cursor to RAID card controller column, input “F2” and select “Clear Configuration”.




Figure 0-9 Clear RAID configuration information